

# LOWLANDER MK4 MANURE SPREADER – INSTRUCTION & SPARES MANUAL

Thank you for buying a Bunning spreader. For your Bunning guarantee please fill in the form below and return it to G.T. Bunning Ltd.

LOWLANDER WARRANTY REGISTRATION FORM	
Customer Name	
Company Name	
Address	
Post Code	
Telephone	
Fax	
Email	
Machine ID Number	
ID No. Example 01/01/9999/U/MSL75	
Date of delivery	
Dealer	

## Important Data Protection Information.

We or our business partners may contract you by mail, telephone, e-mail or other electronic messaging services with offers of goods and services or information that may be of interest to you.

By providing us with your telephone number or e-mail address you consent to being contacted by these methods.

If you do not wish to receive marketing information by these methods from GT Bunning or our business partners please tick this box.

☐

GT Bunning & Sons Ltd  
The Green  
Gressenhall, Dereham  
Norfolk  
NR20 4DT ENGLAND

<b>Bunning Lowlander Mk4</b>		
<b>Pre-Delivery Inspection sheet</b>		
<p>The purpose of this document is to ensure that the operator, hirer or owner is fully appraised of all safety guidelines and operating and maintenance methods before taking possession of the machine.</p>		
<b>GENERAL</b>		
<b>1</b>	Ensure the operator receives a copy of the instruction & spares manual.	
<b>2</b>	Draw attention to the safety decals located on the machine.	
<b>3</b>	Explain the functions of the machine.	
<b>4</b>	Locate, identify & explain spreader to towing vehicle air, hydraulic and electric connectors.	
<b>5</b>	Check oil level of floor drive gearbox and auger drive gearbox.	
<b>6</b>	Explain how to cut the PTO guard to size and where to fit the safety chains.	
<b>LIGHTING</b>		
<b>12</b>	Check operation of lights	
<b>13</b>	Check condition of cabling & 7 pin connector.	
<b>BRAKING</b>		
<b>7</b>	Check operation of parking brake.	
<b>8</b>	Check operation of service brake.	
<b>STRUCTURE</b>		
<b>9</b>	Check condition of body, drawbar & augers	
<b>10</b>	Check condition of all cylinders & pins.	
<b>11</b>	Grease all points if necessary. (see manual).	
<b>HYDRAULICS &amp; PNEUMATICS</b>		
<b>14</b>	Check hydraulic hose condition especially brake hoses & connectors.	
<b>15</b>	Check hydraulic cylinder for leaks and damage.	
<b>16</b>	Check air system hose condition and connectors. (Option).	
<b>WHEELS &amp; TYRES</b>		
<b>17</b>	Check condition of tyres.	
<b>18</b>	Ensure tyre pressures are correct for speed & load.	
<b>19</b>	Check wheel nut torque. (Check daily for first week of use)	
<b>DATE:</b>		<b>SIGNATURE</b>
<p>I have received a copy of the instruction &amp; spares manual and understand the method of operation, the safety requirements and the maintenance methods.</p>		<b>OPERATOR</b>
<p>I have given basic instruction in the method of operation, the position of safety stickers and methods of maintenance, and ensured that the owner/operator is in possession of the Manual.</p>		<b>DEALER</b>

# CHASSIS SERIAL NUMBER.....

SECTION & CONTENTS	PAGE
Preface	7
How to use this manual	7
Operating on public roads	7
Introduction	8
Disposal	8
EC Declaration of Conformity	9
Machine over view	10
 1. OPERATING INSTRUCTIONS	
1.1 Hitching to tractor.	11
1.2 Coupling of hydraulic hoses.	12
1.3 Hand brake.	13
1.4 Brake adjustment.	13
1.5 Floor adjustment.	13
1.6 Method of operation.	13
1.7 Slurry door.	13
1.8 Installation and general use of detachable spinner deck.	14
1.9 Horizontal beaters operation.	16
 2. MAINTENANCE	
2.1 Lubrication of spreader.	17
2.2 Servicing intervals.	17
2.3 Service record.	21
2.4 Shearbolt protection.	22
2.5 Greasing points.	22
 <u>DRAWINGS AND PARTS LISTS</u>	
3. FLOOR DRIVE	
3.1 Hydraulic circuit for floor drive.	23
3.2 Floor speed control unit.	25
3.3 Floor drive relief valves.	26
3.4 Floor drive gearbox MK4 75/90/105/120.	27
3.5 Floor drive gearbox MK4 150.	29
3.6 Rear floor shaft assembly MK4.	31
3.7 Front shaft and chains MK4.	33

<b>4</b>	<b>AUGERS AND DRIVES</b>	
4.1	Shredding augers MK4.	35
4.2	Shredding augers WB.	37
4.3	Horizontal beater with spinning discs.	39
4.4	Coupling assembly spinner deck horizontal beater.	41
4.5	Gearbox Standard 540 / 360 - B3172.	43
4.6	Gearbox Standard 1000/420 - B3170.	45
4.7	Gearbox Widebody augers 1000 / 350 - B3180.	47
4.8	Gearbox Spinner deck through drive 1000 / 420 - B3175.	49
4.9	Gearbox Detachable spinner deck 1000/520 - B3190.	51
4.10	Gearbox Horizontal beater 1000/520 - B3192.	53
4.11	Transverse drive assembly horizontal beaters.	55
4.12	Tranverse gearbox horizontal beaters.	56
<b>5.</b>	<b>P.T.O AND TRANSMISSION</b>	
5.1	MK4 Transmission model 75 & 105C.	57
5.2	MK4 Transmission model 90/105/105HY/150C.	58
5.3	MK4 Transmission model 120/120HY.	59
5.4	MK4 Transmission model 150/150HY.	60
5.5	MK4 Horizontal beater transmission.	60
5.6	Problems and possible solutions.	61
5.7	Comer series V PTO shaft assembly.	63
5.8	Comer standard guard complete shear bolt.	64
5.9	Comer wide angle guard complete.	64
5.10	Walterscheid torque limiter complete 6 spline wideangle	65
5.11	Comer wide angle grease points	65
5.12	Comer T60 underbody driveshaft.	66
5.13	Comer plastic guard assembly.	67
5.14	Comer guard safety chain fixing.	68
5.15	PTO stowage.	70
<b>6.</b>	<b>BRAKE &amp; AXLE ARRANGEMENTS</b>	
6.1	MK4 brake arrangement 120/150.	71
6.2	Brake parts MK4 75/90/105/105C.	73
6.3	Axle hub and bearing parts MK4.	74
6.4	Hydraulic brake ram assembly 30mm bore MK4 75.	76
6.5	Hydraulic brake ram assembly 35mm bore. MK4 90/105/120/150 .	77
6.6	Hydraulic brake circuit – single axle.	78
6.7	Hydraulic brake circuit – rear drawbar clevis.	79

<b>7.</b>	<b>AXLES &amp; SPRUNG DRAWBAR</b>	
	Safety notice.	80
	General information.	81
	Axle maintenance and adjustment.	82
	Sprung drawbar spring information.	93
	Minimum program of maintenance sheet.	94
<b>8.</b>	<b>TYRES AND WHEELS</b>	
8.1	Tyre and wheel maintenance.	95
8.2	Pressure settings standard tyres.	96
8.3	Wheel type and torque settings.	102
<b>9.</b>	<b>OPTIONS</b>	
9.1	Sprung drawbar.	103
9.2	Rear clevis drawbar.	104
9.3	Guillotine slurry door MK4.	105
9.4	Guillotine slurry door MK4 horizontal beaters.	106
9.5	Guillotine slurry door hydraulic circuit drawing.	107
9.6	Support Leg.	108
9.7	Toolbox.	109
9.8	Sludge cake kit.	110
9.9	Detachable Spinner deck kit.	111
9.10	Handbrake control multi-stroke MS45.	112
9.11	Auger deck rubbers MK4 & WB.	112
9.12	Simple canopy.	113
9.13	Hydraulic border control.	113
9.14	Automatic rear lamps.	114
9.15	Manual rear lamps.	115
9.16	Weigh cell spares.	116
<b>10.</b>	<b>ELECTRICS</b>	
10.1	Wiring for 12v 7 pin plug.	117
10.2	Rear lamps.	118
10.3	Marker lamp.	118

<b>11.</b>	<b>HEALTH AND SAFETY &amp; POTENTIAL HAZARDS</b>	
11.1	Hazardous machinery warning.	119
11.2	Loss of control.	119
11.3	Operation around bystanders.	119
11.4	Hydraulic fluid penetration or burning.	119
11.5	Electrocution.	119
11.6	Body entry.	119
11.7	Coupling / decoupling.	119
11.8	Machinery start up.	120
11.9	Machinery shut down.	120
11.10	Additional driver protection.	120
11.11	PTO Connection and guarding.	120
11.12	Personal protective equipemnt.	120
11.13	Safety decal location.	120
11.14	Operating hazard area.	121
11.15	Warnings	122
<b>12.</b>	<b>WARRANTY</b>	<b>122</b>
<b>13.</b>	<b>IMPORTANT INFORMATION</b>	<b>123</b>
<b>14.</b>	<b>NOTES</b>	<b>124</b>
<b>15.</b>	<b>IDENTIFICATION PLATE</b>	<b>125</b>
<b>16.</b>	<b>TECHNICAL DATA &amp; SPECIFICATIONS</b>	<b>126</b>
<b>17.</b>	<b>MACHINE DIMENSIONS</b>	<b>127</b>

\*\*

THIS MANUAL IS THE ORIGINAL INSTRUCTIONS

\*\*

## PREFACE

The instructions in the manual must be read carefully and followed by all persons concerned with the operation, maintenance, repair or inspection of this machine in order to prevent accidents.

Especially read sections relating to safety, operating instructions and maintenance.

The use of spare parts, accessories and additional equipment which is not originally manufactured checked and release by GT Bunning Ltd can have a negative effect on specific design features of the machine and on its operability. This may impair its operating safety, as well as safety at work for the operator and could invalidate warranty.

GT Bunning will in no way be liable for damage or personal injury caused by the use of other than original GT Bunning parts, accessories and additional equipment.

Technical specifications, dimensions and weights are given with the usual tolerances **(+ or -2%)**.

GT Bunning Ltd operates a policy of continual improvement; as such some items in this manual may differ slightly from that of your machine. GT Bunning reserves the right to make changes to the machine or manual without notice. If in any doubt regarding any aspect of the design or operation of this machine contact GT Bunning Ltd or your GT Bunning Ltd agent for clarification.

## HOW TO USE THIS MANUAL

The manual contains sections that cover all of the following, Safety, Operating instructions, Maintenance, Specifications and Technical data. Refer to the contents pages for the relevant page number.

Before use of the machine familiarise yourself with the manual and its contents

The machine should only be operated, serviced and repaired by persons who are familiar with the machine and who have read and understood this manual, and are informed of the risks.

**This manual should stay with the machine/operator at all times.**

## OPERATING ON PUBLIC ROADS

Before operating on public roads the spreader must be correctly connected to the towing vehicle, the lights must be connected and function of the lighting equipment must be checked. The braking system of the spreader must be correctly connected to the towing vehicle, check for correct operation. **Remember, max gross combination weight is 24390Kg and maximum gross spreader weight is 18290kg. If your spreader is wider then 2.55m and up to 3.5m your maximum speed is 20 mph, above 3.5m is 12 mph.**

## **INTRODUCTION**

This manual provides information on the use, adjustment and servicing of the GT Bunning range of Lowlander spreader.

Following the advice on the correct maintenance and servicing procedures will ensure maximum performance and a long service life of your machine.

Failure to carry out maintenance work correctly or incorrect operation will result in poor machine efficiency and loss of valuable time.

By ensuring the correct operation, and by carrying out maintenance and service work with care, you will be able to make full use of the technical knowledge and the experience with which your Lowlander spreader was originally designed.

## **DISPOSAL**

Upon completion of the useful life of the machine, all parts can be disposed of at a suitable waste disposal facility.

Care must be taken if oxy-acetylene cutting equipment is to be used.

The wheels and tyres, hydraulic cylinders, valves and hoses must be removed before using cutting equipment.

Oil must be drained collected and disposed of in accordance with current legislation.

Electrical components must be disposed of in accordance with the relevant legislation.



## **G.T.BUNNING & SONS LIMITED**

SPREADERS, TRAILERS & TANKS

Telephone: 01362 860352

Fax: 01362 860930

E-mail: [sales@gtbunning.co.uk](mailto:sales@gtbunning.co.uk)

[www.gtbunning.co.uk](http://www.gtbunning.co.uk)

Registered Office:

Smithy House,

TheGreen

Gressenhall, Dereham

Norfolk, NR20 4DT

### EC MACHINERY DIRECTIVE 2006/42/EC DECLARATION OF CONFORMITY

We hereby certify that the machinery stipulated below complies with all the relevant provisions of the EC Machinery Directive 2000/42/EC & regulations adopting the Directive.

Modifications to this machine without prior written approval from the undersigned will render the declaration null & void.

**Machine Description:** Unbalanced trailer for the carriage & application of manure

**Machine Type:** Agricultural manure spreader

**Model:** Lowlander MSL

**Serial Number:**        /        /        /U/MSL

Standards used.

BS ISO 4251-1:2005+A1:2012, BS EN ISO 12100-1:2010, BS EN ISO 4254-1:2009, BS EN 690: 1994+A1:2009,  
BS EN 15811: 2009, BS EN ISO 13857:2008, BS EN 349:1993+A1:2008, BS EN 12965:2003+A2:2009,  
BS EN 953:1997+A1:2009, BS EN ISO 5674:2009, BS ISO 4413:2010.

Signed


Name: Greg Shepherd



Date :

Position: Joint Managing Director

## MACHINE OVER VIEW



KEY	QTY	DESCRIPTION
1	1	BODY
2	1	DRAWBAR
3	1	STONE GUARD
4	1	FRONT PILLAR
5	1	PTO DRIVE LINE
6	1	FINGER GUARD
7	1	SUPPORT LEG
8	1	LADDER
9	2	WHEEL & TYRE ASSEMBLY
10	1	AUGER GEARBOX
11	1	FLOOR DRIVE GEARBOX, MOTOR AND VALVE
12	2	AUGER
13	2	LAMP ASSEMBLY
14	1	AXLE

## 1. OPERATING INSTRUCTIONS

The intended purpose of the vehicle is to tow and spread manure and other materials.

### 1.1 Hitching to tractor.

Attach spreader to pick-up hook or static hitch stub. Do not attach to swinging drawbar or pick-up hook in extended position.



Remove screwjack from drawbar (if fitted) and locate in transport position provided at the front of spreader.

#### **Turn off the tractor and remove key before fitting PTO.**

Slide the tractor end of the PTO shaft out and fit to the tractor PTO. Lay the two halves of the PTO shaft alongside one another and mark the required lengths, allowing for turning. Maximum pull out of 300mm (12 inches) of the 2 shafts. Cut to size and clean burrs at each end of shaft **KEEP SHAFT SLIDING SURFACES GREASED**. Attach chains fitted to PTO guard (to prevent rotation of guard) to suitable point on the tractor and hole provided on metal cover over PTO shaft on spreader. Ensure that the spring loaded pins in splined yokes are fully locked in position. Always disengage the PTO when turning sharply to avoid damage to shafts universal joints. Where a wide angle PTO is fitted attach this end to the tractor. **Please refer to the DVD for more information.**

## 1.2 Coupling of hydraulic hoses.


Fit the two hoses for the floor drive hydraulic motor (one to feed and one for return) to double spool valve on tractor. Choose position of spool lever for ease of control to obtain floor movement to rear. Reversing of floor is done by selecting the opposite position of the hydraulic control lever. Universal quick release probes are fitted as standard to hose ends. Mark hose as required to assist in the future coupling for correct position of feed and return. When a slurry door is fitted connect the hydraulic hoses to a double spool valve and select the hose positions to suit the operator to open and close the door.

Fit hydraulic brake hose to trailer brake valve on tractor (male fitting).  
A universal female brake coupling is fitted as standard to the hose ends.

### **N.B CHECK DIRECTION OF FLOOR BEFORE LOADING.**

Do not run floor in reverse with full load. Speed of floor in reverse is at **MAXIMUM**.  
Only reverse floor for a few seconds.

**Ensure the braking system is connected and that it functions correctly before moving.**



### 1.3 Hand brake.

The handbrake is a multi-stroke ratchet type. To apply the handbrake give the handle short pumps (a clicking of the ratchet will be heard) until resistance occurs and subsequent tightening of the cable. To release the handbrake give the handle one sharp movement in the opposite direction. This releases the ratchet mechanism.

### 1.4 Brake adjustment.

Brake adjustment is carried out at the hydraulic brake ram unit fitted to each wheel axle giving independent adjustment to each wheel. To adjust, jack up the spreader, slacken the locknut in the set screw and turn the set screw clockwise. (See section 7)

**BEWARE NOT TO OVER ADJUST.** Make sure the wheel can rotate freely.

### 1.5 Floor adjustment.

When adjusting floor chains ensure that the adjustment is carried out equally to both sides.

**DO NOT ALLOW THE CHAINS TO BECOME TOO SLACK.**

**ADJUST CHAINS AFTER A FEW LOADS.**

**KEEP CHAINS ADJUSTED CORRECTLY AT ALL TIMES, A GUIDE IS TO BE ABLE TO SEE A WHOLE LINK BELOW FRONT SIDE OF THE SPREADER i.e. FROM CENTRE TO FRONT POST.**

#### **Reverse floor**

The floor should only be reversed for very short periods, to clear the augers.

**Do not** reverse if the floor chain is slack, tighten floor chain first.

### 1.6 Method of operation.

- 1) Select speed of floor required on control valve.
- 2) Engage PTO to power the rear augers – tractor engine revs low.
- 3) Raise slurry door if fitted.
- 4) Engage spool valve to power floor to rear.

### 1.7 Slurry Door

As the load height reduces lower the slurry door to cover the augers. This will help prevent foreign objects being thrown forward.

## 1.8 INSTALLATION AND GENERAL USE OF DETACHABLE SPINNER DECK

### GENERAL USE

The detachable spinner deck is designed purely for wider spread patterns and low application rates of between 1 and 3 tonnes per acre (2 ½ to 7 ½ tonnes per hectare). It must **NEVER** be used to spread long straw based material or heavy applications beyond 5 tonnes per acre.


### INSTALLATION

When fitting or removing the spinner deck assembly great care must be taken not to endanger an assistant in any way, especially when raising or lowering the unit. Persons must not be put at risk.

**Before making any adjustments, fitting or removing attachments, the tractor that the spreader is attached to must be switched off and the key removed.**

### FITTING THE SPINNER DECK

- 1 Remove guard from output spigots of the auger gearbox.
- 2 Slide one half of 'flexi coupling' onto the shaft, through shaft of spinner gearbox.
- 3 Slide other half of the 'flexi coupling' on the input spigot of the spinner gearbox.
- 4 Using approved lifting apparatus lift the complete spinner deck assembly using lower lifting eye on canopy.
- 5 Offer the assembly to rear of the machine and lower into position. Firstly locate the 'bucket hooks' of deck into clevises at the top rear corners of the spreader.
- 6 Hinge hook bolt No. 14 into anchors and tighten.
- 7 Fit and tighten 4 bolts to join the two halves of the flexi coupling.
- 8 The machine is now ready for use with the spinner deck.




## REMOVING THE SPINNER DECK

- 1 Clean all material from spinners and decks.
- 2 Remove 4 bolts from the flexi coupling.
- 3 Loosen hook bolts No. 14 and hinge back to clear anchors.
- 4 Using approved lifting apparatus lift from lower lifting eye on the canopy firstly pulling the bottom of the deck assembly away from rear of spreader to the clear auger blades.
- 5 Lift the assembly clear of the spreader and stand on level ground with the front of the assembly close to, or against a wall or stable object.
- 6 Fit the shaft cover to the output spigot of the spreader auger gearbox.
- 7 The machine is now ready for use without spinner deck.

## ADJUSTMENT OF CANOPY & BLADES

For the best results

- 1 Fix the canopy on the inner positions for light materials i.e. Poultry manure.
- 2 For heavy material i.e. slurry or sludge adjust canopy out as far as possible so as not to deposit material beyond the deck into gaps between the discs.
- 3 To increase the width of the spread pattern adjust the angle of blades forward on the disc.
- 4 If the spread pattern is light immediately behind the machine adjust the angle of the blades back.
- 5 It is possible to achieve an even spread by adjusting the blades, as opposing pairs. i.e. Blade 1 and 3 position 3 and blade 2 and 4 in position 1.



## 1.9 OPERATING INSTRUCTIONS FOR HORIZONTAL BEATERS

### General use

The horizontal beater with spinner discs is designed primarily for wider spread patterns and lower application rates for product such as chicken and turkey manure, however long straw based materials can be spread effectively. It must be expected that application rates may be slower than a vertical auger spreader.

### Adjustments for spread patterns

The position of the lower section of rear canopy and the angle of the blades on the discs will affect the spread pattern and width.

Select a hole position that places the rubber strip over the middle of the discs for a lighter application rates and wider widths. Adjust the hole position to move the rubber strip rearwards for higher application rates e.g. for straw based materials. Excessive rearward adjustment will cause the material to miss the discs and hit the ground without being spread.

Each spinning disc is supplied with 2 blades on and the others loose; it has been proven that many materials are spread more effectively with just 2 blades per disc.

- 1 To increase the width of the spread pattern adjust the angle of blades forward on the disc.
- 2 If the spread pattern is light immediately behind the machine adjust the angle of the blades back.
- 3 With 4 blades fitted it is possible to achieve an even spread by adjusting the blades, as opposing pairs. i.e. Blade 1 and 3 in position 3 and blade 2 and 4 in position 1.
- 4 When adjusting angle use the 2nd set of holes on the blade to keep the tip of the blade on the edge of the disc



Change angle of lower canopy here.

Rubber strip pointing at the centre of the spinning discs.



## 2. MAINTENANCE

### 2.1 Lubrication of spreader.

<b>DAILY GREASE</b>	Front and rear floor shaft Overrun clutch to front of main 'T' gearbox Hitch eye
<b>WEEKLY GREASE</b>	All sealed bearing – 1/2 pump of grease gun maximum.

#### TAKE CARE NOT TO DAMAGE GREASE SEAL BY OVERGREASING

Sliding tube of PTO shaft.  
PTO universal joints – **Follow manufacturers instructions.**  
Screwjack top (when fitted)  
Shearbolt bush

<b>MONTHLY</b>	Check gearbox oil levels
<b>ANNUALLY</b>	Change oil to all gearboxes
<b>TYPE OF LUBRICATION GREASE</b>	Multi purpose
<b>GEARBOXES</b>	EP90


### 2.2 Servicing intervals

The period recommended is based on normal operating conditions. Severe or unusual conditions may require more frequent lubrication or oil changes.

**IMPORTANT:** *ENSURE CV JOINT IS GREASED BEFORE FIRST USE!*  
*TAKE CARE NOT TO DAMAGE SEALS BY OVERGREASING.*

#### DAILY (8 HRS)


1. Check for hydraulic fluid leaks and damaged hoses.
2. Grease Front and Rear floor chain shaft bearings.
  - a. Front shaft.
    - Remove front Finger Guard to access bearings.




## LOWLANDER MK4 MANURE SPREADER – INSTRUCTION & SPARES MANUAL

### b. Rear Shaft.

- Grease both left and right bearings.



### 3. Grease the Overrun Clutch to front of the auger gearbox.



## WEEKLY (40 HRS)

1. Check wheel nuts. Re-torque as needed.
2. Grease all sealed bearings
  - a. Driveline hanger bearings (2 or 3 depending on model).
  - b. Top auger bearings (Grease nipples access provided on right turret).
3. Grease the telescoping section of the PTO shaft.

4. Grease PTO input drive system.
  - a. Input shaft.
  - b. Cross joint fittings.
  - c. Guard bearings.
  - d. Shear bolt housing.
  - e. Over-running clutch (5 pumps).
5. Grease the implement jack top.
6. Check gearbox oil level
  - a. Floor Chain Drive Gearbox
    - Oil should be level with the middle of the sight glass.
    - Add oil as required through the top plug.
  - b. Auger Gearbox
    - Spreader must be unhooked from tractor and set on level ground to check oil. Oil should be level with the middle of the sight glass.
    - Add oil as required through the top plug.
    - Oil may take a while to distribute in casing, recheck level after 30 – 40 minutes and repeat if necessary.



#### MONTHLY

1. Apply grease or heavy oil to apron chain.
2. Grease telescoping section of PTO shaft.
3. Grease the CV Joint of PTO shaft (15 pumps)

4. Grease suspension system spring bushings on each side.
5. Grease brake pivot bushings (Tandem Suspension machines).
6. Grease parking brake leaver joint.
7. Check and adjust the apron chain tension. Refer to section 5.2.2 - page 50.

## ANNUALLY

1. Change oil to all gearboxes.
2. Check the condition of the frame sealing flaps. Replace if not sealing the sides or bottom.
  - a. Front.
  - b. Rear    Slurry Door    Auger Deck.
3. Check brake setting.

Brakes can be checked by depressing the brake petal with the engine running and the tractor in gear; release clutch to determine brake adjustment.

4. Check condition of rotor blades and paddles. Repair when there are loose bolts, cracked welds, chipped, bent or broken blades or paddles. Replace when any components are worn within 1 inch (25 mm) of flighting.
5. Clean machine.
6. Check general hardware/bolt tightness. Retighten if necessary.

*It is recommended to apply waste oil to the floor chains periodically when spreading dry material and particularly at the end of the spreading season. This assists in the smooth running of the machine and prolongs the working life of the components.*

7. Check bearings in gearboxes.

See Lubrication and Maintenance sections for details of service. Copy this page to continue record.

G = GREASE

---

Page


21

## 2.4 Shearbolt Protection.

Only one shearbolt is fitted to the spreader. This is located on the spreader end of the PTO shaft. The bolt is M10 x 60 grade 6.8 mild steel.

**ON NO ACCOUNT MUST A BOLT OF HIGHER GRADE THAN 6.8 TENSILE STRENGTH BE FITTED.**


## 2.5 Greasing points



KEY	GREASE POINT
1	ALL BEARINGS IN DRIVE LINE
2	FRONT SHAFT
3	PTO KNUCKLES
4	REAR SHAFT
5	BEARINGS TOP OF AUGERS (GREASE POINT O/S ON TURRET)

### 3. FLOOR DRIVE

#### 3.1 HYDRAULIC CIRCUIT FOR FLOOR DRIVE




### 3.1 HYDRAULIC CIRCUIT FOR FLOOR DRIVE PARTS LIST

KEY	QTY	PART No.	DESCRIPTION
1	1	B3000	FLOW CONTROL 45 LPM
1	1	B3004	ELECTRIC FLOW CONTROL 45 LPM
1	1	B3001	FLOW CONTROL 76 LPM
1	1	B3005	ELECTRIC FLOW CONTROL 76 LPM
2	3	51593	3/4" BONDED SEAL
3	4	51591	1/2" BONDED SEAL
4	1	51590	3/8" BONDED SEAL
5	2	51337	3/4" TO 3/8" ADAPTOR
6	1	51340	3/4" / 1/2" ADAPTOR
7	2	51336	1/2" TO 3/8" ADAPTOR
8			
9	2	51464	1/2" BULKHEAD
10			
11	1	51447	3/8" MALE TEE
12	1	51412	1/2" MALE/FEMALE 90 DEG
13	1	51414	3/8" MALE/FEMALE 90 DEG
14			
15	1	51393	1/2" TO 3/8" FEMALE/FEMALE
16			
17			
18	1	51576	1/2" MALE PROBE
19	2	B4400	HYD HOSE 230mm
20	1	B4401	HYD HOSE 610mm
21			
22	2	B4414	HYD HOSE 2500mm
		B4415	EXPORT 2440mm
23		B4416	HYD HOSE FLOW 75 & 105C
		B4418	HYD HOSE FLOW 90
		B4420	HYD HOSE FLOW 105
		B4422	HYD HOSE FLOW 120
		B4424	HYD HOSE FLOW 150
24		B4417	HYD HOSE RETURN 75 & 105C
		B4419	HYD HOSE RETURN 90
		B4421	HYD HOSE RETURN 105
		B4423	HYD HOSE RETURN 120
		B4425	HYD HOSE RETURN 150
26	1	B3068	DOUBLE CROSS LINE RELIEF VALVE




### 3.2 FLOOR SPEED CONTROL UNIT – PART No. B3000



KEY	QTY	DESCRIPTION
1	1	O RING
2	1	BACK-UP RING
3	1	O RING
4	1	SET SCREW
5	1	ADJUSTER SCREW
6	1	ADJUSTING KNOB
7	1	INDEX SPRING
8	1	PLUG
9	1	CONTROL SLEEVE
10	1	SCREW
11	1	PLUG
12	1	O RING
13	1	BODY
14	1	PLUG
15	1	NEEDLE VALVE

### 3.3 FLOOR DRIVE RELIEF VALVES

This valve is cross line type and fitted to the hydraulic motor on the floor drive gearbox. The pressure can be varied to suit the material being spread. To adjust, engage the oil flow via the spool valve on the tractor, slacken the locknut and insert an allen key and turn clockwise to increase pressure until the floor starts to move. Tighten the locknut. To decrease the pressure, reverse procedure. When making this adjustment, the spreader pressure should be set lower than the tractor PRV.



#### To adjust relief valve pressure

##### No.1

Cartridge controls movement of floor to rear. To increase pressure release locknut turn screw clockwise and retighten locknut.

To decrease pressure turn screw anticlockwise.

##### No.2


Cartridge controls movement of floor to front. To increase pressure release locknut turn screw clockwise and retighten locknut.

To decrease pressure turn screw anticlockwise.

#### **NOTE**

Maximum protection can be given to moving parts by keeping relief valve pressure set to a minimum.

### 3.4 FLOOR DRIVE GEARBOX MK4 75/90/105/105C/120 – B3105 500/50/25



Note:


Motor not shown Part No. **B3040**

When a hybrid machine (WB beaters) or with 20mm floor chains the gearbox used is B3106 500/60/25. See the item 2 on the table for the parts difference.

### 3.4 FLOOR DRIVE GEARBOX MK4 75/90/105/105C/120 – B3105 PARTS LIST

<u>KEY</u>	<u>QTY</u>	<u>PART No.</u>	<u>DESCRIPTION</u>
1	1	B3203	CASING
2	1	B3228	SLEEVE M50
2	1	B3229	SLEEVE M60 (W.B BEATERS & )
3	1	B4099	CIRCLIP
4	1	B3231	GEAR
5	2	BR320	BEARING
6	2	B4015	CIRCLIP
7	1	B3237	PINION SHAFT
8	2	B2271	KEY
9	1	B3234	GEAR
10	2	BR350	BEARING
11	3	B4006	CIRCLIP
12	1	B3232	PINION SHAFT
13	1	B2270K	KEY
14	1	B3238	CROWN BEVEL
15	1	B3478	SPACER
16	2	BR375	BEARING
17	2	B4002	CIRCLIP
18	1	B3233	PINION SHAFT
19	1	BR310	BEARING
20	1	B4019	CIRCLIP
21	2	B3997	BREATHER PLUG
22	2	B3995	SIGHT GUAGE
23	2	SL255	CAP SEAL
24	2	SL265	CAP SEAL
25	2	SL200	SEAL
26	1	B3222	GASKET
27	1	B3218	COVER PLATE
28	8	73030/1	BOLT
29	1	B3226	GASKET

### 3.5 FLOOR DRIVE GEARBOX MK4 150 – B3122 800/60/32



Note:


Motor not shown Part No. **B3052**

### 3.5 FLOOR DRIVE GEARBOX MK4 150 – B3120 PARTS LIST

KEY	QTY	PART No.	DESCRIPTION
1	1	B3204	CASING
2	1	B3230	SLEEVE
3	1	B4030	CIRCLIP
4	1	B3236	GEAR
5	2	BR325	BEARING
6	2	B4016	CIRCLIP
7	1	B3240	PINION
8	2	B2276	KEY
9	1	B3244	GEAR
10	2	BR365	BEARING
11	2	B4012	CIRCLIP
12	1	B3242	PINION
13	1	B2270L	KEY
14	1	B3248	CROWN GEAR
15	2	BR390	BEARING
16	3	B4006	CIRCLIP
17	1	B3252	PINION
18	1	BR310	BEARING
19	1	B4019	CIRCLIP
20	2	B3997	BREATHER BUNG
21	2	B3995	SIGHT GLASS
22	2	SL265	CAP SEAL
23	2	SL270	CAP SEAL
24	2	SL205	SEAL
25	1	B3224	GASKET
26	1	B3220	COVER PLATE
27	8	73030/1	BOLT
28	1	B3227	GASKET

**NOTE: 60mm Rear shaft.**

### 3.6 REAR FLOOR SHAFT ASSEMBLY




### 3.6 REAR FLOOR SHAFT ASSEMBLY PARTS LIST

KEY	QTY	PART No.	DESCRIPTION
1	1	B2250	REAR SHAFT M50
	1	B2254	REAR SHAFT M60 MK4 150 ONLY
	1	B2256	REAR SHAFT M60 MK4 WITH W.B BEATERS
2	2	B2100	GYPSY WHEEL M50 MK4 75-120
	2	B2102	GYPSY WHEEL M60 MK4 WITH W.B BEATERS & 150
3	2	B2300	BEARING FLANGE M50
	2	B2302	BEARING FLANGE M60
4	2	B2320	ACM BUSH M50
	2	B2322	ACM BUSH M60
5	2	B2280	END PLATE M60
6	4	B1101/1	BOLT & WASHER M14
7	4	BOLT	M12 x 35
8	1	B3105	GEARBOX 75/90/105/105C/120
	1	B3106	GEARBOX WITH W.B BEATERS
	1	B3120	GEARBOX 150 ONLY
9	1	B3212	TORQUE PLATE 75/90/105/105C/120
	1	B3214	TORQUE PLATE 150 ONLY
10	1	B3040	HYDRUALIC MOTOR
11	2	B2274	KEY FOR M50 SHAFT
	2	B2275	KEY FOR M60 SHAFT
12	1	B2277	KEY FOR M50 SHAFT
	1	B2278	KEY FOR M60 SHAFT
13	1	B2348	SPACER 150 ONLY
14	4	WASHER	SPRING WASHER M12
15	2	B2122	REAR GYPSY SCRAPER
16	1	B2822	DRIVE SHAFT COVER MK4
17	2	B2124	MOUNT PLATE FOR SCRAPER



### 3.7 FRONT SHAFT AND CHAIN ASSEMBLY




### 3.7 FRONT SHAFT AND CHAIN ASSEMBLY PARTS LIST

KEY	QTY	PART No.	DESCRIPTION
1	22	B2012	BOX FLOOR SLAT MK4 75/105C
	28	B2012	BOX FLOOR SLAT MK4 90/105/150C
	30	B2012	BOX FLOOR SLAT MK4 120
	33	B2012	BOX FLOOR SLAT MK4 150
2	2	B2286	ADJUSTERS M24 MK4
	2	B2288	ADJUSTERS M30 MK4 150 ONLY
3	2	B2202	JOINER LINK
4	2	B2126	FRONT CLEANER
5	4	73031	BOLT
6	2	B2320	BUSH M50
	2	B2322	BUSH M60 MK4 150 ONLY
7	2	B2290	BEARING HOUSING M50
	2	B2294	BEARING HOUSING M60 MK4 150 ONLY
8	2	B2345	SPACER M50
	2	B2346	SPACER M60 MK4 150 ONLY
9	1PR	B2152	FLOOR CHAIN 28FT STD SPACED TAB EVERY 4TH LINK 75/105C
	1PR	B2162	FLOOR CHAIN 35FT STD SPACED TAB EVERY 4TH LINK 90/105
	1PR	B2172	FLOOR CHAIN 37FT STD SPACED TAB EVERY 4TH LINK 120
	1PR	B2182	FLOOR CHAIN 40FT STD SPACED TAB EVERY 4TH LINK 150
	1PR	B2154	FLOOR CHAIN 28FT CLOSE TAB EVERY 2ND LINK 75/105C
	1PR	B2164	FLOOR CHAIN 35FT CLOSE TAB EVERY 2ND LINK 90/105
	1PR	B2174	FLOOR CHAIN 37FT CLOSE TAB EVERY 2ND LINK 120
	1PR	B2184	FLOOR CHAIN 40FT CLOSE TAB EVERY 2ND LINK 150
10	1	B2220	SHAFT M50
	1	B2222	SHAFT M60 FOR MK4 150 ONLY
11	1	B2214	PLATE WHEEL SET OF 4
	1	B2218	PLATE WHEEL SET OF 4 MK4 150 ONLY
12	2	50726	GREASE NIPPLE
13	55	B2015	105MSL 50x30x4 BOX SLAT USED ON HBD
13	59	B2015	120MSL 50x30x4 BOX SLAT USED ON HBD
13	65	B2015	150MSL 50x30x4 BOX SLAT USED ON HBD

## 4 AUGERS AND DRIVES

### 4.1 SHREDDING AUGER MK4




#### 4.1 SHREDDING AUGERS MK4 PARTS LIST

KEY	QTY	PART No.	DESCRIPTION
1	1	B1021	AUGER R.H 75/90
	1	B1031	AUGER R.H 105/105C/120/150/150C
2	1	B1020	AUGER L.H 75/90
	1	B1030	AUGER L.H 105/105C/120/150/150C
3	2	B1152	DRIVE FLANGE
4	12	B1142	RUBBER DRIVE BLOCK
5	3	B1122	BLADE BORON EACH AUGER
6	44	B1100/1	CUTTER 75/90 BORON *
	56	B1100/1	CUTTER 105/105C/120/150 BORON
7	100	B1103	BOLT & NUT 75/90
	124	B1103	BOLT & NUT 105/105C/120/150
8	2	B1178/1	BEARING
9	2	B1160	BEARING COVER
10	2	B2350	SPACER
11		B1106	ANGLE THROWER - OPTION
12	8	B1105	BOLT & NUT
13	44	B1098	REINFORCING BAR
14	4	73154	16 x 45 BOLT

\* B1100 CUTTER STEEL EN8.

#### 4.2 SHREDDING AUGER MK2 HD & WIDE BODY




#### 4.2 SHREDDING AUGER MK2 HD & WIDE BODY PARTS LIST

KEY	QTY	PART No.	DESCRIPTION
1	1	B1044	AUGER L.H
2	1	B1045	AUGER R.H
3	2	B1156	DRIVE FLANGE
4	12	B1146	RUBBER DRIVE BLOCK W.B MK2
5	8	B1122	AUGER BLADE BORON
6		B1103	BOLT & LOCKNUT
7		B1105	BOLT & LOCKNUT FOR STD CUTTER & ANGLE THROWER
8		B1101/1	BOLT & NYLOC FOR H.D CUTTERS
9		B1100/1	CUTTER POINT STD BORON *
9		B1101/B	CUTTER POINT H.D BORON *
10		B1106	ANGLE THROWER OPTIONAL
11	2	B2352	SPACER
12	2	B1180/1	BEARING M60
13	2	B1162	BEARING COVER
14	8	B1105	BOLT & LOCKNUT

\* B1100 CUTTER STEEL EN8.

\* B1101 CUTER STEEL EN8

### 4.3 HORIZONTAL BEATER x 2 WITH SPINNING DISC




#### 4.3 HORIZONTAL BEATER x 2 WITH SPINNING DISC PARTS LIST

KEY	QTY	PART No.	DESCRIPTION
1	2	B4138	RAM 50mm BORE 1626mm STROKE
2	1	B4158	RUBBER SEAL
3	2	65093	12" CANOPY RAM
4	2	BC442	TAPERLOCK BUSH 3020/50
5	1	BC258	30T SINGLE SPROCKET 3020
6	1	BC120	1" SINGLE CHAIN
7	1	BC248	25T SINGLE SPROCKET
8	1	BC436	TAPERLOCK BUSH 2517/60
9	1	B3122	FLOOR DRIVE GEARBOX
10	1	B8220	TOP SHAFT
11	1	B8226	BOTTOM SHAFT
12	18	B1101/4A	BEATER KNIFE TOP CUTTER
13	2	70009/3	REAR LAMP
14	18	B1101/7A	BEATER KNIFE BOTTOM CUTTER
15	1	B3190	SPINNER GEARBOX
16	1	BC294	25T DUPLEX SPROCKET
17	1	BC445	TAPERLOCK BUSH 3020/60
18	1	BC140	1" DUPLEX CHAIN
20	1	BC290	23T DUPLEX SPROCKET 3020
21	1	B8450	TOP DOOR
22	1	B8451	BOTTOM DOOR
23	1	B4161	CANOPY RUBBER
24	2 & 2	B1118 / B1119	PADDLE RH & LH
25	1	B8246	SPINNING DISC RH
26	1	B8245	SPINNING DISC LH
27	1	BC214	11T TENSIONER SINGLE SPROCKET
28	1	BC222	11T TENSIONER SINGLE DUPLEX
29	8	B8354/B8355	PADDLE HOLDER LH/RH
30	1	B4160	SPINNER DECK RUBBER
31	2	AMS0984	CHAIN GUARD
32	1	DMS2583-1	TRANSVERSE DRIVE GUARD
33	1	AMS0689-1	TRANSVERSE DRIVE ASSEMBLY
34	1	AMS0064	COUPLING ASSEMBLY
35	1	B3084	TEE GEARBOX
36	1	DMS2521	MOUNT TOP PLATE
37	1	AMS1524	GEARBOX GUARD
38	2 & 3	B1180/1 & B1178/1	BEARING MSF 60 BRG & MSF 50 BRG
39	2	AMS0940-2	BOTTOM RAM PIN
40	1	B4172	RUBBER SEAL CANOPY
41	1	DMS2595	CLAMP ANGLE
42	2	DMS1781-1	CANOPY LID
43	2	DMS2381	PIVOT PIN
44	2	DM0940-1	TOP RAM PIN




#### 4.4 COUPLING ASSEMBLY SPINNER DECK HBD PART No. AMS0064



**4.4 COUPLING ASSEMBLY SPINNER DECK HBD PART No. AMS0064 PARTS LIST**

KEY	QTY	PART No.	DESCRIPTION
1	1	B8484	TUBE CONNECTING DRIVE ASSY
2	1	B8486	DRIVE COUPLING ASSY 1 3/8"
3	1	B8488	DRIVE COUPLING ASY 1 3/4"
4	6	B1142	RUBBER SEGMENT 127 O/D x 50mm I/D
5	6	B1142	RUBBER SEGMENT 127 O/D x 74mm I/D


#### 4.5 GEARBOX 540/360 STANDARD PART No. B3172



#### 4.5 GEARBOX 540/360 STANDARD PART No. B3172 PARTS LIST

<u>KEY</u>	<u>QTY</u>	<u>PART No.</u>	<u>DESCRIPTION</u>
1	1	B3404	CASING
2	1	B3410	EXTENSION
3	1	B3494	GASKET
4	4	BR175	BEARING
5	1	B3440	SHAFT
6	2	B3510	NUT LH THREAD
7	3	B3520	WASHER
8	1	SL165	SEAL
9	1	B3400	CASING R.H
10	2	B3492	GASKET
11	1	B4014	CIRCLIP
12	1	BR410	BEARING
13	2	B3442	SHAFT
14	2	B3480	SPACER
15	2	BR180	BEARING
16	2	BR405	BEARING
17	2	B3482	SLEEVE
18	2	B3420	TOP PLATE
19	2	SL195	SEAL
20	2	B3490	GASKET
21	2	B4007	CIRCLIP
22	1	B3402	CASING
23	1	B3446	SHAFT
24	1	B4020	CIRCLIP
25	1	B3512	NUT R.H THREAD
26	2	SL275	CAP SEAL
27	1	B3998	PLUG
28	1	B3996	SIGHT GLASS
29	1	B3990	DRAIN BUNG
30	22	73125	BOLT
31	12	73124	BOLT
32	2	B3939	O -RING
33	3	B3454	PINION
34	3	B3464	GEAR
35	2	B3420	DRIVE ASSEMBLY
36	1	B3409/1	NOSE CONE ASSEMBLY


#### 4.6 GEARBOX 1000/420 STANDARD PART No. B3170



#### 4.6 GEARBOX 1000/420 STANDARD PART No. B3170 PARTS LIST

<u>KEY</u>	<u>QTY</u>	<u>PART No.</u>	<u>DESCRIPTION</u>
1	1	B3404	CASING
2	1	B3410	EXTENSION
3	1	B3494	GASKET
4	4	BR175	BEARING
5	1	B3440	SHAFT
6	2	B3510	NUT LH THREAD
7	3	B3520	WASHER
8	1	SL165	SEAL
9	1	B3400	CASING
10	2	B3492	GASKET
11	1	B4014	CIRCLIP
12	1	B3866	BEARING
13	2	B3442	SHAFT
14	2	B3480	SPACER
15	2	B3466	CROWN GEAR
16	2	BR180	BEARING
17	2	BR405	BEARING
18	2	B3482	SLEEVE
19	2	B3420	TOP PLATE
20	2	SL195	SEAL
21	2	B3490	GASKET
22	2	B4007	CIRCLIP
23	1	B3402	CASING
24	1	B3446	SHAFT
25	2	B3456	PINION GEAR
26	1	B4020	CIRCLIP
27	1	B3512	NUT RH THREAD
28	2	SL275	CAP SEAL
29	1	B3998	PLUG
30	1	B3996	SIGHT GLASS
31	1	B3990	DRAIN BUNG
32	22	73125	BOLT
33	12	73124	BOLT
34	2	B3939	O RING
35	1	B3458	PINION GEAR
36	1	B3468	PINION GEAR
37	2	B3420	DRIVE ASSEMBLY
38	1	B3409	NOSE CONE ASSEMBLY

#### 4.7 GEARBOX 1000/350 WIDEBODY PART No. B3180



#### 4.7 GEARBOX 1000/350 WIDEBODY PART No. B3180 PARTS LIST

<u>KEY</u>	<u>QTY</u>	<u>PART No.</u>	<u>DESCRIPTION</u>
1	1	B3510	NUT
2	3	B3520	LOCKING WASHER
3	3	B3460	PINION GEAR
4	4	BR175	BEARING
5	1	BR410	BEARING
6	3	B3470	CROWN GEAR
7	1	B4020	CIRCLIP
8	2	B3510	NUT
9	1	B3448	CROSS SHAFT
10	2	B3482	SPACER SLEEVE
11	2	B3939	O RING
12	12	73124	BOLT
13	2	B3420	TOP PLATE
14	2	B3490	GASKET
15	2	SL195	SEAL
16	2	BR405	BEARING
17	2	B3444	OUTPUT SHAFT
18	2	B3480	GEAR SPACER
19	2	BR180	BEARING
20	2	B3412	OUTER CASE SECTION
21	54	73125	BOLT
22	6	B3492	GASKET
23	2	B3418	AUGER GEAR CASE
24	1	B3414	INNER CASE SECTION
25	1	B3404	CENTRE CASE
26	1	B3417	INNER CASE SECTION
27	1	B3998	BREATHER PLUG
28	1	B3996	SIGHT GLASS
29	1	B3990	DRAIN PLUG
30	1	B3494	GASKET EXT
31	1	B3410	EXTENSION
32	1	B3440	INPUT SHAFT
33	1	SL165	SEAL
34	2	B3420	DRIVE ASSEMBLY
35	1	B3408	NOSE CONE ASSEMBLY




This exploded view diagram illustrates the assembly of a mechanical component, likely a pump or valve. The parts are numbered 1 through 38. Callout 37 points to a sub-assembly consisting of parts 18, 32, 21, 14, 15, and 16. Callout 38, enclosed in a dashed box, points to a sub-assembly consisting of parts 3, 5, 31, 8, 4, and 2. The main assembly sequence starts with the housing (10) and shaft (1), followed by the impeller (15) and various seals and bearings (14, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28, 29, 30, 31, 32, 33, 34, 35, 36, 37, 38).

#### 4.8 GEARBOX SPINNER DECK 1000/420 PART No. B3175.

KEY	QTY	PART No.	DESCRIPTION
1	1		CASING
2	2	B3410	EXTENSION
3	2	B3494	GASKET
4	6	BR175	BEARING
5	1	B3440	SHAFT
6	2	B3510	NUT LH THREAD
7	4	B3520	WASHER
8	2	SL165	SEAL
9	1	B3400	CASING
10	2	B3492	GASKET
11	1	B4014	CIRCLIP
12	1	BR410	BEARING
13	2	B3442	SHAFT
14	2	B3480	SPACER
15	2	B3466	CROWN GEAR
16	2	BR180	BEARING
17	2	BR405	BEARING
18	2	B3482	SLEEVE
19	2	B3420	TOP PLATE
20	2	SL195	SEAL
21	2	B3490	GASKET
22	2	B4007	CIRCLIP
23	1	B3402	CASING
24	1	B3446	SHAFT
25	2	B3456	PINION GEAR
26	1	B4020	CIRCLIP
27	2	B3512	NUT RH THREAD
28	2	SL275	CAP SEAL
29	1	B3998	PLUG
30	1	B3996	SIGHT GLASS
31	2	B3990	DRAIN BUNG
32	22	73125	BOLT
33	12	B3939	O RING
34	2	B3458	PINION GEAR
35	1	B3468	PINION GEAR
36	1		SHAFT
37	2	B3420	DRIVE ASSEMBLY
38	1	B3409	NOSE CONE ASSEMBLY


#### 4.9 GEARBOX SPINNER DECK 1000/520 PART No. B3190



#### 4.9 GEARBOX SPINNER DECK 1000/520 PART No. B3190 PARTS LIST

KEY	QTY	PART No.	DESCRIPTION
1	1	B3405	CASING
2	1	B3494	GASKET
3	1	B3410	EXTENSION
4	4	BR175	BEARING
5	1	B3440	SHAFT
6	1	B3454	PINION GEAR
7	1	B3510	NUT LH THREAD
8	1	SL165	SEAL
9	3	B3520	WASHER
10	6	B3492	GASKET
11	2	B3420	TOP PLATE
12	1	B3415R	INNER CASE SECTION
13	1	BR410	BEARING
14	1	B3416R	INNER CASE SECTION
15	1	B3449R	CROSS SHAFT
16	1	B3464	PINION GEAR
17	1	B3430	CIRCLIP
18	2	B3459	PINION GEAR
19	2	B3512	NUT
20	2	B3418	AUGER GEAR CASE
21	2	BR405	BEARING
22	2	SL195	SEAL
23	2	B3444	OUTPUT SHATF
24	2	B3490	GASKET
25	2	B3480	SPACER
26	2	B3469	CROWN GEAR
27	2	BR180	BEARING
28	2	B3482	SLEEVE
29	2	B3939	O RING
30	12	73124	BOLT
31	2	B3413	OUTER CASE SECTION
32	1	B3998	PLUG
33	1	B3996	SIGHT GLASS
34	1	B3990	DRAIN BUNG
35	54	73125	BOLT
36	1	B3408/1	NOSE CONE ASSEMBLY
37	2	B3420	DRIVE ASSEMBLY


#### 4.10 GEARBOX HORIZONTAL BEATER 1000/520 PART No. B3192



#### 4.10 GEARBOX HORIZONTAL BEATER 1000/520 PART No. B3192 PARTS LIST


<u>KEY</u>	<u>QTY</u>	<u>PART No.</u>	<u>DESCRIPTION</u>
1	1	B3405	CASING
2	1	B3494	GASKET
3	1	B3410	EXTENSION
4	4	BR175	BEARING
5	1	B3440	SHAFT
6	1	B3454	PINION GEAR
7	2	B3510	NUT
8	1	SL165	SEAL
9	3	B3520	WASHER
10	6	B3492	GASKET
11	2	B3420	TOP PLATE
12	1	B3415	INNER CASE SECTION
13	1	BR410	BEARING
14	1	B3416	INNER CASE SECTION
15	1	B3450	SHAFT
16	1	B3464	PINION GEAR
17	1	B4020	CIRCLIP
18	2	B3459	PINION GEAR
19	1	B3512	NUT RH THREAD
20	2	B3418	AUGER GEAR CASING
21	2	BR405	BEARING
22	2	SL195	SEAL
23	2	B3444	OUTPUT SHAFT
24	2	B3490	GASKET
25	2	B3480	SPACER CROWN GEAR
26	2	B3469	CROWN GEAR
27	2	BR180	BEARING
28	2	B3482	SPACER SLEEVE
29	2	B3939	O RING
30	12	73124	BOLT
31	2	B3413	OUTER CASE SECTION
32	1	B3998	BREATHER PLUG
33	1	B3996	SIGHT GLASS
34	1	B3990	DRAIN PLUG
35	54	73128	BOLT
36	1	B3408/1	NOSE CONE ASSEMBLY
37	2	B3420	DRIVE ASSEMBLY

#### 4.11 TRANSVERSE DRIVE ASSEMBLY HORIZONTAL BEATERS – AMS0689



KEY	QTY	PART No.	DESCRIPTION
1	1	42760	YOKE
2	1	42701	JOURNAL
3	1	42755	YOKE
4	1		KEY WAY 12x8x40 lg
5	1		KEY WAY 14x9x51 lg
6	1	73898	GRUB SCREW M12x16 lg
7	1	B8440	DRIVE SHAFT

#### 4.12 TRANSVERSE GEARBOX HORIZONTAL BEATERS




KEY	QTY	PART No.	DESCRIPTION
1	1		CASING
2	1		OIL FILLER PLUG 1/2" GAS
3	24		BOLT M10X22 8,8
4	2		COVER
5	1	BR140	BEARING
6	2	SL110	OIL SEAL
7	1		SHAFT
8	1		SHIM
9	1		SNAP RING
10	2		BOLT M10X22 8,8
11	1		EXTENSION
12	1		SHAFT
13	1		NUT
14	1	SL175	OIL SEAL
15	2		COPPER WASHER
16	2	BR115	BEARING
17	1		SHIM
18	1		CROWN WHEEL
19	1	BR105	BEARING
20	1		SHIM KIT
21	1		PLUG
22	1		PINION SHIM
23	1		SHIM




## 5. P.T.O AND TRANSMISSION

### 5.1 MK4 TRANSMISSION MODEL 75/105C




KEY	QTY	PART No.	DESCRIPTION
1	1	42260	PTO SHAFT F/M
2	1	42301	PTO SHAFT M/M SHORT
3	1	42300	PTO SHAFT F/F
4	2	B1170/1	BEARING M35
5	1	AMS1524	GUARD
6	1	B3170	GEARBOX
7	1	B1173	BRG MSF35 FRONT ONLY

## 5.2 MK4 TRANSMISSION MODEL 90/105/105HY/150C




<u>KEY</u>	<u>QTY</u>	<u>PART No.</u>	<u>DESCRIPTION</u>
1	1	42260	PTO SHAFT F/M
2	1	42302	PTO SHAFT M/M
3	1	42300	PTO SHAFT F/F
4	3	B1170/1	BEARING M35
5	1	AMS1524	GUARD
6	1	B3170	GEARBOX
7	1	B1173	BRG MSF35 FRONT ONLY

### 5.3 MK4 TRANSMISSION 120/120HY



KEY	QTY	PART No.	DESCRIPTION
1	1	42260	PTO SHAFT F/M
2	1	42301	PTO SHAFT M/M
3	1	42250	PTO SHAFT F/M
4	1	42300	PTO SHAFT F/F
5	2	B1170/1	BEARING M35
6	1	AMS1524	GUARD
7	1	B3170	GEARBOX
8	1	B1173	BGR MSF35 FRONT ONLY

#### 5.4 MK4 TRANSMISSION MODEL 150/150HY







KEY	QTY	PART No.	DESCRIPTION
1	1	42260	PTO SHAFT F/M
2	1	42301	PTO SHAFT M/M
3	1	42255	PTO SHAFT F/M
4	1	42300	PTO SHAFT F/F
5	3	B1170/1	BEARING M35
6	1	AMS1524	GUARD
7	1	B3170	GEARBOX
8	1	B1173	BGR MSF35 FRONT ONLY

#### 5.5 MK4 TRANSMISSION FOR HORIZONTAL BEATERS






MODEL	FRONT	MIDDLE	REAR
105HB	42260	42250	42270
120HB	42260	42255	42270
150HB	42260	42250 x 2	42270

**Note:** Cut PTO shaft 42270 to suit.


## 5.6 PROBLEMS AND POSSIBLE SOLUTIONS

PROBLEM	PROBABLE CAUSE	POSSIBLE SOLUTION
 <p>Torsion of telescopic tubes</p>	Excessive twisting of shafts	Fit an appropriate safety device onto the drive
 <p>Rapid wear on tubes</p>	Excessive slipping under load of drive Drive too short so tubes are not coupled well	Upgrade the drive Use drive polyamide coated tubes. (Rilsan coated) Replace drive with one of an adequate length
 <p>Rapid wear on shielding ring nuts</p>	Poor lubrication	Lubricate as prescribed
 <p>Shielding coming out of its seat and chain giving way</p>	Poor lubrication	Lubricate as prescribed
	Bad chain connection	Position chain properly so that even at the maximum drive angle the chain is not under tension

## 5.6 PROBLEMS AND POSSIBLE SOLUTIONS

PROBLEM	PROBABLE CAUSE	POSSIBLE SOLUTION
 Yoke eyes opening / deforming	Excessive twisting of shafts	Fit an appropriate safety device onto the drive
 Wear on yoke arms	Drive too long	Upgrade the drive
 Cross pins break	Excessive twisting movement	Fit an appropriate safety device onto the drive Upgrade the drive
 Rapid wear on cross pins	Excessive continuous load or excessive working angle Lubrication intervals not respected	Check that the choice of working conditions and type are appropriate Respect the prescribed lubrication intervals
 Telescopic tubes disengaging during work or manoeuvring	Drive too short	Replace drive with a longer one

## 5.7 COMER SERIES V PTO SHAFT ASSEMBLY.



KEY	QTY	DESCRIPTION	PART No.
1	1	W/A YOKE 6 SPLINE 1 $\frac{3}{8}$	42810
1	1	W/A YOKE 21 SPLINE 1 $\frac{3}{8}$	42815
1	1	W/A YOKE 20 SPLINE 1 $\frac{3}{4}$	42825
2	2	W/A JOURNAL	42848
3	1	W/A CENTRAL BODY	42845
4	1	W/A YOKE TO OUTER	42830
5	1	MULTI LOBE OUTER TUBE	42780
6	1	MULTI LOBE INNER TUBE	42785
7	1	YOKE TO INNER MULTI LOBE	42835
8	1	ROLL PIN	42792
9	1	ROLL PIN	42790
10	1	T60 YOKE TO SHEARBOLT	42760
11	1	T60 JOURNAL	42701
12	1	SHEARBOLT 4.6	B1310
12	1	SHEARBOLT 6.8	B1311
12	1	SHEARBOLT 8.8	B1312
12	1	SHEARBOLT 10.9	B1313

## 5.8 COMER STANDARD GUARD COMPLETE SHEAR BOLT



SHEAR BOLT

<u>KEY</u>	<u>QTY</u>	<u>DESCRIPTION</u>	<u>PART No.</u>
1	1	T60 STD COMER PTO 6 SPLINE	42210
2	1	T60 STD COMER PTO 21 SPLINE	42220

## 5.9 COMER WIDE ANGLE GUARD COMPLETE 42242 6 SPLINE, 42244 21 SPLINE.




<u>KEY</u>	<u>QTY</u>	<u>DESCRIPTION</u>	<u>PART No.</u>
1	1	PLASTIC GUARD INNER & OUTER	42910
2	1	W/A CONE	42920
3	1	W/A GUARD COMPLETE	42088




**5.10 WALTERSCHEID TORQUE LIMITER COMPLETE 6 SPLINE W/A PART No. 43006TL**



**5.11 COMER WIDE ANGLE GREASE POINTS**




## 5.12 COMER T60 UNDERBODY DRIVESHAFT.



KEY	QTY	DESCRIPTION	PART No.
1	1	SPLINED BAR	42041
2	1	T60 INNER TUBE (PER METER)	42775
3	1	T60 OUTER TUBE(PER METER)	42770
4	1	YOKE TO OUTER	42745
5	1	ROLL PIN	42030
6	1	JOURNAL	42701
7	1	YOKE 6 SPLINE CLAMP BOLT	42715
7	1	1 1/4 YOKE 6 SPLINE OVERRUN CLAMPBOLT	42766
8	1	1 1/4 6 SPLINE YOKE QUICK RELEASE SHEARBOLT	42760
9	1	1 1/4 6 SPLINE YOKE QUICK RELEASE SHEARBOLT	42705
9	1	1 1/4 21 SPLINE YOKE QUICK RELEASE SHEARBOLT	42725
9	1	1 1/4 21 SPLINE YOKE QUICK RELEASE SHEARBOLT	42740
10	1	YOKE TO INNER	42750
11	1	ROLL PIN	42790
12	1	ROLL PIN	42792

### 5.13 COMER PLASTIC GUARD ASSEMBLY.



<u>KEY</u>	<u>QTY</u>	<u>DESCRIPTION</u>	<u>PART No.</u>
1	1	PLASTIC GUARD COMPLETE	42910
2	1	SAFETY CHAIN	42058
3	1	BEARING RING INNER	42056
4	1	BEARING RING OUTER	42057

## **5.14 COMER PTO GUARD SAFETY CHAIN FIXING**

Care should be taken when fixing the PTO safety chains, by following the guidelines below you can help avoid unnecessary and possibly expensive damage to the PTO guard and its component parts.

SEE DVD OR LOCAL DEALER.

The purpose of the safety chain is to stop the guarding from rotating during its normal operation thus preventing foreign objects becoming entangled in it including you!, the safety chains must be fixed in a position that limits the risk of damage to both operator and shaft guarding.

Because each application varies there is no one perfect way of fitting, as we are all aware tractors vary as do machines, some come with ideal fixing points others don't. The chains are supplied at a set length, this is not the length they have to be used at, more so the length exists to ensure attachment can be achieved should a suitable anchor point be some distance from the guard.

In the case where a chain can be shortened it should be, not so much as to then cause damage by pulling on the guard but enough to stop the whole chain wrapping around the guard cuffs as the shaft starts to work. This is especially true when fixing wide angle constant velocity joints, by its nature the shaft will be moving to the left and right as the tractor turns, in this case we have to leave enough slack on the chain to allow this movement but at the same time ensuring that the chain does not wrap around the wide angle cover or pull across its surface causing damage, in an ideal world the chain would be fixed at 90 degrees to the guard, in effect the only point of contact between guard and chain would be where the chain is fixed to the guard, getting the anchor point as close to 90 degrees to the shaft will certainly help prevent damage.

Sometimes with the wide angle shafts it is possible to fix one chain to the other, at the same time shortening the length of chain as it is done, this can be achieved by taking the main tube guard chain that is at the wide angle end of the drive shaft and clipping it to the chain running from the wide angle guard which in turn is anchored as close to 90 degrees from the shaft as is possible, again providing there is some slack left in the chain, the length of chain can be reduced thus avoiding damage caused by excess chain wrap around and crossover.

The following pointers should help keep your guard serviceable for many hours.

1. Don't leave the chains too long allowing them to wrap around the guard it will damage the guard.
2. Don't leave the chains so short they pull on the guard.
3. Always try and avoid contact between chain and guard, keep contact to a minimum.
4. Anchor the chains as close to 90 degrees from the shaft as possible.
5. If needed attach one chain to the other, to avoid cross over and chain wrap around.
6. Always ensure there is enough slack to allow for exaggerated movement especially when using a wide angle shaft.
7. Always maintain the shaft as instructed by the manual supplied with it.
8. Grease your shaft and guard bearings regularly.
9. Always replace worn chains and guarding, damaged guards are potentially lethal.
10. Always stop the tractor engine, wait for the machine to stop turning and remove the ignition key before attempting to work on or around your driveshaft.

**Refer to DVD supplied.**

Safety chain fixing positions



Grease points tractor end

Grease points machine end

For more information on fitting and maintaining your Comer PTO see:-

[www.youtube.com/watch?v=dDxK0e9rA9E](http://www.youtube.com/watch?v=dDxK0e9rA9E)



### 5.15 PTO STOWAGE




**When the spreader is not in use stow PTO as shown to prevent damage.**

Please check the condition of the PTO guard regularly, if damaged replace as soon as possible.

## 6. BRAKE & AXLE ARRANGEMENTS

### 6.1 MK4 BRAKE ARRANGMENT 120/150 & WB




## 6.1 MK4 BRAKE ARRANGMENT 120/150 & WB PARTS LIST

		MODEL	120	150/180
		AXLE SIZE	140mm SQ	150mm SQ
		BRAKE TYPE	412S	414S
KEY	QTY	DESCRIPTION	PART No.	PART No.
1	2	DRUM	F10017/6	F10017/7
2	4	LINING	97726D08	97726013
3	2	S' CAM ROD	97831	97831
4	2	WASHER	97770008	97770008
5	4	BUSH	97610568	97610568
6	4	GREASER	50731/3	50731/3
7	2	CIRCLIP 42E	98900042	98900042
8	2	BACK COVER PER PAIR	F10123/4	F10123/5
9	2	RUBBER BOOT	97610575	97610575
10	2	BUSH	771382601	771382601
11	2	BRAKE LEVER	F1030	F1030
12	2	CIRCLIP	98900025	98900025
13	2	WASHER	92630030	92630030
14	10	NUT	92411008	92411008
15	2	TAB WASHER	97610579	97610579
16	2	STUD	97620583	97620583
17	2 PR	BRAKE SHOE	F10108/2	F10108/3
18	2	SPRING TENSIONER	97610576	97610576
19	4	RETURN SPRING	738119	738119




## 6.2 MK4 BRAKE PARTS MK4 75/90/105/105C



	MODEL	75/105C	90/105
	AXLE SIZE	EF938	EUR 1010/1110
	BRAKE TYPE	A 410	A 610
	BRAKE SIZE	355 x 80	400 x 80
<b>KEY</b>	<b>DESCRIPTION</b>	<b>PART No.</b>	<b>PART No.</b>
1	BRAKE SHOES	F10107	F10108/1
2	BRAKE ROD BUSH	97610514	97610514
3	CIRCLIP 38E	98900038	98900038
4	BRAKE LEVER	F00620	F00620
5	NUT	57524B2	57524B2
6	PIN 4 x 32	98850432	98850432
7	CIRCLIP	98900025	98900025
8	RETURN SPRING	738123	738117
9	DRUM	F10017/4	F10017/5


### 6.3 AXLE HUB AND BEARING PARTS MK4



### 6.3 AXLE HUB AND BEARING PARTS MK4 PARTS LIST


	MODEL	75	90,105&105C	120	150
	AXLE TYPE	EF 938	EUR 1010/1110	EUR 1410	EUR 1520
	AXLE SIZE	90mm	100/110mm	140mm	150mm
<b>KEY</b>	<b>DESCRIPTION</b>	<b>PART No.</b>	<b>PART No.</b>	<b>PART No.</b>	<b>PART No.</b>
1	AXLE	J1020	J1030/40	J1050	J1060
2 4 6	SEAL KIT	F10061/3	F10061/4	F10061/5	F10061/6
3	BEARING	BR210	BR240	BR228	BR245
5	HUB	F10016/1	F10016/2	F10016/2	F10016/3
7	BEARING OUTER	BR195	BR250	BR250	BR240
8	CASTLE NUT	F10066/1	F10066/2	F10066/2	F10066/2
9	PIN	J1060F1	J1060F1	J1060F1	J1060F1
10	HUB CAP GASKET				
11	HUB CAP	F10073	F10073/1	F10073/1	F10073/2
12	HUB CAP SCREW				
	WHEEL NUT	F00550	F00547	F00547	F00547
	WHEEL STUD	F00545/1	F00546	F00546	F00546

#### 6.4 HYDRAULIC BRAKE RAM ASSEMBLY – MK4 75 30mm BORE – 70830.2




KEY	QTY	PART No.	DESCRIPTION
1	2	70830/2	RAM ASSEMBLY
2	2	70831/2	SEAL KIT
3	2	70830/4	SPRING & PIN KIT
4	2	70836	SELLOCK PIN
5	2	70835/2	CYLINDER
6	2	70834	ADJUSTER

## 6.5 HYDRAULIC BRAKE RAM ASSEMBLY - MK4 90/105/105c/120/150. 35mm BORE – 70830.3



KEY	QTY	PART No.	DESCRIPTION
1	2	70830/3	RAM ASSEMBLY
2	2	70831/3	SEAL KIT
3	2	70830/4	SPRING & PIN KIT
4	2	70836	SELLOCK PIN
5	2	70835/3	CYLINDER
6	2	70834	ADJUSTER


## 6.6 HYDRAULIC BRAKE CIRCUIT SINGLE AXLE



KEY	QTY	PART No.	DESCRIPTION
1	1	51568	COUPLING 3/8 FEMALE SELF SEAL
2	1	51583-1	DUMMY 3/8 MALE
3	1	51463	3/8"-3/8" NPT BULKHEAD
4	2	51447	3/8"-3/8"-3/8" NPT MALE TEE
7	1	B4462	INTER-CONNECTING HOSE
8	2	B4454	AXLE HOSE
9	1	B4458	LONG HOSE
14	REF		BRAKE ACTUATOR HYDRAULIC

**Note: 75 and 105C are the same and so are the 90,105 & 150C.**

## 6.7 HYDRAULIC BRAKE CIRCUIT & CLEVIS DRAWBAR



KEY	QTY	PART No.	DESCRIPTION
1	1	51568	COUPLING 3/8 FEMALE SELF SEAL
2	1	51583-1	DUMMY 3/8 MALE
3	1	51463	3/8"-3/8" NPT BULHKHEAD
4	2	51447	3/8"-3/8"-3/8" NPT MALE TEE
7	1	B4462	INTER-CONNECTING HOSE
8	2	B4454	AXLE HOSE
9	1	B4458	LONG HOSE
10	1		HOSE DIA3/8" BORE 2 WIRE x 1020
11	1		HOSE DIA3/8" BORE 2 WIRE x 2800
12	1	51644	ADAPTOR 3/8" MALE-M20x1.5 FEM
13	1	51569	COUPLING 3/8 MALE SELF SEAL
14	REF		BRAKE ACTUATOR HYDRAULIC

**Note:** 75 and 105C are the same and so are the 90,105 & 150C.

## 7.

### AXLES



## 1. SAFETY NOTICE

---

*The authors and publisher are not liable for any physical damage or personal injury resulting from errors or omissions in this manual.*

This manual does not replace the manual provided by the vehicle manufacturer.

Maintenance must be carried out by suitably qualified personnel using appropriate tools.

This manual describes everyday maintenance operations and does not cover major repairs.

We recommend that maintenance should be carried out by a specialised workshop.

*Carrying out repairs and maintenance work may be dangerous. This safety notice describes only some of the potential hazards and is intended to make users aware of the risks and encourage them to take care.*

#### **Personal protection :**

Wear appropriate personal protection equipment: goggles, mask, gloves, helmet, safety shoes, overalls, etc.  
Work in the presence of another person.

#### **Unstable vehicles :**

Never work underneath or near a vehicle that has been raised using only a jack.  
When working underneath or near a vehicle that has been jacked up, always make sure that the jack is used in conjunction with stands or other effective supports and that the jack and stands used can bear the weight.  
Check that the vehicle is perfectly stable and that the forces applied to the vehicle while carrying out maintenance will not cause it to shift. Also check that the ground is firm.

#### **Hot parts :**

Some parts, such as brake drums, for example, may become extremely hot in use.

#### **Pressurised hydraulic or pneumatic systems :**

NB: Before carrying out maintenance on hydraulic or pneumatic systems, which may be pressurised, take all necessary precautions to avoid accidental pressure release.

#### **Risk of fire, risks from fumes, toxic gases and irritant substances :**

All fuel is highly flammable and petroleum vapour is explosive.  
For cleaning and degreasing parts, use only appropriate, recognised cleaning fluids and follow the instructions on the packaging.  
Avoid contact with the skin and avoid inhaling vapour, fumes or toxic gases.  
Do not smoke, use a naked flame or create sparks, etc if there is a risk of explosion or fire owing to the presence of flammable vapours, fuel, oil, paint, solvents, dust, straw, etc.  
A fire extinguisher appropriate for the type of risk should always be to hand.

#### **Asbestos :**

The brake linings of our axles no longer contain asbestos. We used asbestos-free linings well before EU regulations prohibited its use.  
If there is any doubt about the presence of asbestos (for example, when carrying out maintenance on old axles), the brakes and linings should be handled as if they contained asbestos, as asbestos dust is a major health hazard.



## General information.



## 2. AXLES

---

### 2.1 General

The specifications of our axles and suspensions can be found in the general COLAERT ESSIEUX catalogue. The catalogue provides the following information.

#### Axles

- The axle cross-section.
- The axle type.
- The axle loads and maximum admissible offset at speeds of 25, 40 and 60 km/h with zero offset wheels, with single, tandem or tridem axles.
- The number and size of studs and the bolt circle.
- The centre hole diameter.
- The brake dimensions (drum internal diameter and lining width).
- The braking characteristics certified by CEMAGREF and TUV.

The general catalogue also gives the admissible load on the axle assembly for different load offsets. Exceeding these values may cause excessive bending of the axle and possibly permanent damage.

***Stabiliser jacks bearing on the axles, weight transfer devices or lifting axles do not increase the maximum load on the axles or suspensions.***

#### Suspension

- The maximum load for the suspension.
- The wheel-base.
- The type of spring, the number of leaves and the number of fixed leaves.
- The height of the axle assembly unladen and laden, for different axle cross-sections.

## Axle, maintenance and adjustment.

### 2. AXLES



#### 2.2 Axle, maintenance and adjustment

##### 2.2.1 Assembly and fixing of the wheels


Above all to check that the type of wheel used is compatible with the nut of the wheel stud, i.e. all those of table below except the nuts of the type M, to check that the holes of the rim have a conical part in order to receive the spherical part as of nuts DIN, the spherical washer of the plain nuts or the conical part of the nuts with "Bec".

In the case of twin tyres, in order to ensure a good centering, it is necessary to insert a spherical washer between the flask of the hub and the rim except assembly nuts M.

NUT TYP	Spanner	Wheel stud	Tightening torque	Leverage ("L)	Force ("F)
	mm	mm	Nm	mm	Kg
DIN	17	M12x1,5	90	300	30
	19	M14x1,5	130	300	40
	24	M18x1,5	270	450	60
Plain nut + washer	24	M18x1,5	270	450	60
	27	M20x1,5	380	600	60
	30	M22x1,5	510	800	60
"Twin"	24	M18x1,5	270	450	60
	27	M20x1,5	380	600	60
	30	M22x1,5	510	800	60
"M"	-	-	-	-	-
	27	M20x1,5	450	800	55
	32	M22x1,5	650	1000	65
"Bec"	28	M18x1,5	270	450	60
	30	M20x1,5	380	600	60
	32	M22x1,5	510	800	60

##### Tightening of the nuts of wheel

On lately assembled wheels, the nuts can, at the beginning, to loosen itself in consequence of a compressing. It is thus necessary to check the tightening of the nuts after the first course in load. One will proceed in the same way later on after each disassembling of wheels. To tighten the nuts, to use the adapted special spanner. If one uses the machines bolt ones for the nuts of wheel, to regulate the tightening torque well, if not the threading and the metal of the stud and nuts of wheel undergo an overload.



(\*) The 2 last columns of the table are useful as reference for those which do not have a torque spanner or of pneumatic screw driver (see the figure at side).

It is allowed to use an impact spanner for disassembling, but it is absolutely necessary to avoid the tightening of the nuts with this type of spanner, because the exerted couple is unverifiable.



## 2. AXLES

---

### 2.2.2 Tightening and retightening wheel nuts (Summary) :

*Never use impact wrenches to tighten the wheel nuts as the impact torque may be excessive.*

*Wheel nuts should be tightened diagonally using a torque wrench.*

*If power tools are used (for example, pneumatic torque wrench) they must be carefully set to the required torque for tightening.*

*Otherwise, the studs and wheel nuts may be overtightened which may damage or break them.*

Retighten the wheel nuts after:

- The first time of use.
- The first laden journey.
- The first 1,000 km.
- Every 6 months or 25,000 km.

*Repeat every time the wheels are changed or removed.*

### 2.2.3 Checking the hubcaps

Missing or damaged hubcaps must be replaced immediately to avoid dirt penetrating into the hub which might result in damage to the bearings.

Check that the hub caps are in place and in perfect condition.

For press fit hubcaps, check visually that they are fully home.

For hubcaps attached using screws, fit a new gasket if necessary when the hubcap is removed and retighten the screws regularly (every 6 months).

### 2.2.4 Checking the wheel bearing play

- After the first 1,000 km.
- Before intensive use, every 6 months or 25,000 km.

Wheel bearings are subject to wear: their lifetime depends on the operating conditions, the load, the speed, the adjustment and lubrication, etc.

To check the wheel bearings:

- Lift the wheel off the ground.
- Turn in both directions slowly to check for any rough points or friction
- Turn it at high speed to check for unusual noises, such as grating or knocking.

***If the bearing is damaged or worn, the bearing and seals should all be replaced*** (see paragraph 2.2.7 Replacing the wheel bearings)



## 2. AXLES

- Always err on the side of too free rather than too tight.
- When the hub has been adjusted, fit a new split cotter pin or re-fit the hair-pin clip.
- Refit the hubcap.
- Refit the wheel following the instructions in paragraphs 2.2.1 (Fitting wheels) and 2.2.2 (Tightening and retightening wheel nuts).

When the wheel has been refitted, turn it slightly. It should come to rest with a slow rocking movement due to the imbalance.

### 2.2.6 Lubricating the wheel bearings

In normal operating conditions, lubricate the bearings every 2 years or every 50,000 km and when the brake shoes are replaced.


In harsh conditions the bearings should be lubricated more frequently.

Use a general purpose EP grease formulated for lubricating plain, ball and roller bearings, subject to heavy loads and impacts typical of HGV, agricultural vehicle hubs, etc.

**All parts (hub, spindle, bearings, seals, castle nuts, hubcap, cotter pin) should be degreased and perfectly clean before reassembly.**

The work should be carried out in a clean environment with appropriate tools as the slightest bit of dirt can damage the bearings or even the spindle.

When carrying out maintenance on the bearings, check the brake linings, drum and return springs, clean the brakes, clean and lubricate the brake cam shaft.



**Disassembly :** (See figures 2.2.5 and 2.2.6.a)

- Slacken the wheel nuts.
- Lift the axle until the wheel is off the ground.
- Remove the wheel.
- Release the brakes (make sure that the vehicle cannot move).
- Remove the hubcap.
- Remove the split pin or pin from the spindle.
- Remove the castle nut.



## 2. AXLES

To check the wheel bearing play, raise the axle until the wheel is no longer resting on the ground (**ensure that the vehicle cannot move**).

Release the brake, grip the wheel at the top and the bottom and check the play by trying to tilt it. The play can also be detected by using a lever between the wheel and the ground.


**If you can feel any play, adjust the wheel bearing** (see paragraph 2.2.5 Adjusting the wheel bearings).

**Make sure that the play does not come from the suspension or a steering axle kingpin.**

### 2.2.5 Adjusting the wheel bearings

Lift the axle until the wheel is no longer resting on the ground.

Large wheels should be removed so that the play is easier to feel and to make it easier to adjust the bearings.



- Remove the hubcap.
- Remove the cotter pin or hair-pin clip from the spindle.
- Tighten the castle nut (right-hand thread) to take up the internal play (the conical roller bearings should then be firmly held between the hub seatings, the pressure ring, spindle and castle nut).

**The rotation of the hub or wheel feels to be slightly stiff.**

- Slacken the castle nut until there is no longer any friction between the castle nut and the outer bearing and the hole for the pin is aligned with a notch in the castle nut.
- Tap the hub gently using a mallet to shake down the assembly.
- Check that the hub rotates more freely.

## 2. AXLES




- Remove the drum/hub assembly, using a hub puller if necessary: the outer ring, the grease retaining plates inside the hub (depending on the model), the small bearing cone and cage come with the hub. Check these parts.
- The bearing cups and grease retaining plates can be left inside the hub for cleaning.
- Remove the large bearing cage and cone from the spindle using a bearing puller if necessary.
- Check the oil seal between the spindle and the large bearing (or the wheel bearing seal depending on the model), and replace these parts if necessary. A puller may be required to remove the wheel bearing seal. Note the orientation of the oil seal for reassembly.
- Check the contact surfaces on the spindle for the bearing and seal and the threaded end of the spindle and remove any bumps or asperities.
- Check the hub surfaces in the same way
- Check the bearing face of the castle nut.

***Clean and degrease all parts with a suitable cleaning fluid.***

### ***Reassembly :***

- Grease the spindle lightly.
- Refit the oil seal or wheel bearing seal (ensure that the seal is the right way round), a punch makes it easier to fit the wheel bearing seal and avoids damaging the seal.
- Apply a generous coating of grease to the large bearing cage and rollers, making sure that the grease penetrates all round the rollers and under the cage.
- Fit at bottom the interior ring (cone) of the large bearing on the rocket, it is important to take care not to damage the cage of the bearing, to go up the cone unit, rollers and cage (figure 2.2.6.a) on fixed to use if necessary tools as shown in the figure 2.2.6.b, the effort to push must apply only to the cone, in no case on the cage or the rollers what involves a deterioration of the bearing.
- Apply a 15 mm (small axles) or 20 mm (large axles) layer of grease all around and right across the large and small bearing cups that are still in the hub.
- If the hub does not have grease retaining plates, put a large amount of grease in the centre of the hub to act as a reservoir.
- Slide the hub/drum assembly over the spindle and the brake shoes keeping the hub perfectly straight and aligned until it is in contact with the oil seal at the back of the spindle.
- Apply a generous layer of grease to the small bearing cage and rollers and fit the assembly to the spindle.
- Fit the castle nut and adjust it as described above (See paragraph 2.2.5 Adjusting the wheel bearings).
- Lock the castle nut with a hair-pin clip or new split cotter pin as appropriate.
- For hubs without grease retaining plates, fill the hubcap with grease.
- Refit the hubcap.





## 2. AXLES

### 2.2.7 Replacing the wheel bearing

New grease retaining plates should be fitted to hubs with grease retaining plates (See figure 2.2.5), as the plates will be damaged while removing the bearing cups.


Unpack the bearings at the last moment and never mix them up.

To replace the wheel bearings, follow the instructions for removing the hub (see paragraph 2.2.6 Lubricating the wheel bearings) and remove the bearing cups from the hub as follows.

#### Removing the bearing cups from the hub

Note the orientation of the bearing cups and grease retaining plates for reassembly.

- The bearing cups are an interference fit and must be punched out using a hammer and a mild steel punch (See figure 2.2.7.a).
- If the hub has grease retaining plates, these will be punched out at the same time as the bearing cups and will, therefore, be damaged.



#### Fitting new bearing cups into the hub :


Make sure that the bearing cups and grease retaining plates are the right way round.

**NB: Never fit the bearing cup with the bearing cone and rollers in place**

- If the hub has grease retaining plates, first put the grease retaining plate in its seating (the right way round) and ensure that it remains well centred and in place while the bearing cup is being fitted. Re-check when the operation is complete.
- Fit the bearing cups and punch into place using a mild steel punch as shown in figure 2.2.7.b.

**Take care that the bearing cups are straight and that they are firmly against the seating in the hub.**

## 2. AXLES



### 2.3 Brake maintenance and adjustment

#### 2.3.1 Initial checks

The brakes should be tested before using for the first time and after the first laden journey:

- Check the actuator and return spring mountings, check the actuator stroke and return travel and check that the road and parking brakes operate and release correctly.
- Tighten the screws and nuts (covers, fulcrum, etc), check the cotter pins, pins, circlips, etc.
- Check for hydraulic fluid and air leaks.

#### 2.3.2 Checking brake clearance and wear

Check and test the brakes before intensive use and every 3 months:

- Check the brake wear and the clearance between the brake linings and the drum visually (See figure 2.3.2.a). It is probable that the linings are worn when the actuator travel has increased significantly.
- Check the thickness of the brake linings (See table paragraph 2.3.5 Replacing the brake shoes for the minimum thickness).


***The brake shoes should be replaced as soon as the minimum lining thickness is reached.***

- Check that the brakes are clean and clean them if necessary.
- Lubricate brake cam shaft bearings with grease nipples lightly to avoid grease deposits on the brake linings and drums.
- Carry out the initial checks described above (See paragraph 2.3.1 Initial checks).





## 2. AXLES




### 2.3.3 Adjusting brakes with fixed levers

Take up the slack when the actuator stroke reaches about two thirds of the maximum travel (See figure 2.3.3.a).


To take up the slack, turn the lever by one or more splines, ensuring that the brakes are not touching when released (to prevent overheating the brakes).

Never change the linkage position for the actuator on the lever without authorisation from the vehicle manufacturer as the vehicle will have been tested with the actuator at this position (the brake operating levers have several holes, always use the original hole).

For braking systems with a yoke, the yoke must remain parallel with the axle especially when the brakes are fully applied (See figure 2.3.3.b). This means that the stroke of the levers on the brakes at each side must be identical. Otherwise, the brake slack must be adjusted.



## 2. AXLES



### 2.3.4 Adjusting brakes with adjustable levers

Take up the slack when the actuator stroke reaches about two thirds of the maximum stroke (See also paragraph 2.3.3 Adjusting brakes with fixed levers).


To take up the slack, turn the adjustment screw on the lever to adjust the relative position of the cam and the lever (See figure 2.3.4).

***NB. The actuator brakes by pushing the lever to turn it in a particular direction. The screw must be adjusted so that the cam moves in this direction to take up the slack. The direction in which the screw must be turned depends on the configuration.***

Ensure that the brakes are not touching when released (to prevent overheating the brakes).

***Never change the linkage position for the actuator on the lever without authorisation from the vehicle manufacturer as the vehicle will have been tested with the actuator at this position (the brake operating levers have several holes, always use the original hole)***

For braking systems with a tandem yoke, the yoke must remain parallel with the axle especially when the brakes are fully applied (See figure 2.3.3.b). This means that the stroke of the levers on the brakes at each side must be identical. Otherwise, the brake slack must be adjusted.





## 2. AXLES

### 2.3.5 Replacing the brake shoes

The brake shoes should be replaced as soon as the minimum lining thickness is reached. When replacing the brake shoes, repack the wheel bearings with grease (See paragraph 2.2.6 Lubricating the wheel bearings).

MINIMUM LINING THICKNESS		
BRAKE TYPE	DIMENSIONS (Drum internal diameter and lining width)	Minimum lining THICKNESS
A25	250 x 60	2
A30	300 x 60	2
309E	300 x 90	2
310E	300 x 100	5
314E	300 x 135	5
316	300 x 160	5
A320	350 x 60	2
A410	355 x 80	2
A61	400 x 80	2
408E	400 x 80	2
314S	300 x 135	5
A910	406 x 120	5
A940	406 x 140	5
412S	406 x 120	5
414S	406 x 140	5

See paragraphs 2.2.5 Adjusting the wheel bearings and 2.2.6 Lubricating the wheel bearings for hub disassembly and reassembly and wheel bearing lubrication and adjustment.

**When replacing the brake linings, check all the brake components.**

- Condition of the drums.
- Condition of the cam shafts and levers, in particular check the play in the splines.
- Wear on the bushings.
- Condition of the bellows (depending on the model).
- Condition of the shoe return springs.
- Condition the fulcrums and their mountings (depending on the model).
- Check the rotation of the brake shoe rollers (if fitted) and lightly lubricate before reassembly.


## 2. AXLES



Always replace any worn or damaged parts.

When reassembling, apply a thin coat of grease to all contact surfaces (cams, fulcrums, bushings, etc) being careful to avoid getting any grease on the drums and shoe linings.

*For brakes with an adjustable fulcrum, centre the brake shoes before clamping the fulcrum:  
When the hub/brake assembly has been reassembled, slacken the fulcrum nut slightly, operate the brake lever in the correct direction (direction of the actuator thrust) by pulling on the lever by hand. (It is easier if a pipe is placed over the lever as shown in figure 2.3.5) to press the shoes against the drum.  
Clamp the fulcrum while pressing on the lever.  
If the nut is locked using a split cotter pin, always use a new cotter pin.*





## 9. SPRING DRAWBAR


After the first laden journey, before intensive use or every 6 months (See figure 8)

- Retighten all the mounting U-bolt nuts to the recommended torque *Item 2*.
- Lubricate the attachment shaft *Item 3*.

Under harsh or intensive operating conditions, maintenance should be carried out more frequently.

Every year:

- Check the play between the bushing *Item 4* and the spring drawbar shaft *Item 1*, and, if there is excessive play, replace the worn parts.
- Check the general condition of the spring *Item 5*, clean it thoroughly and brush the sides of the springs to check for cracks. Check the condition of the clamps *Item 6*.





## 11. MINIMUM PROGRAM OF MAINTENANCE



*This maintenance plan is intended for normal operating conditions. More frequent maintenance may be required for harsh operating conditions (construction sites, mountains, intensive use, etc).*

*See the following paragraphs for detailed maintenance instructions.*

on commissioning	after the first laden journey	after the first 1,000 km	every 3 months	every 6 months or 25,000 km	before intensive service	every 2 years or 50,000 km
------------------	-------------------------------	--------------------------	----------------	-----------------------------	--------------------------	----------------------------

### 2.2 Axle maintenance and adjustment

- 2.2.2 Tightening and retightening wheel nuts
- 2.2.3 Checking the hubcaps
- 2.2.4 Checking the wheel bearing play
- 2.2.6 Lubricating the wheel bearings

X	X	X		X		
X				X		
		X		X	X	
						X

### 2.3 Brake maintenance and adjustment

- 2.3.1 Initial checks
- 2.3.2 Checking brake clearance and wear
- 2.3.3 Adjusting brakes with fixed levers
- 2.3.4 Adjusting brakes with adjustable levers

X	X		X		X	
			X		X	
			X		X	
			X		X	

### 3. Steering axles

- 3.2.1 Normal maintenance
- 3.2.2 Checking and adjusting the wheel alignment
- 3.2.3 Locking cylinder maintenance and adjustment
- 3.2.4 Adjusting the clearance, steering axles with tapered pins only
- 3.2.5 Adjusting the steering angle

			X		X	
					X	
					X	
					X	
					X	

### 4. Bogies suspension

	X			X	X	
--	---	--	--	---	---	--

### 5. Basic tandem suspension and basic half-tandem suspension

	X			X	X	
--	---	--	--	---	---	--

### 6. Rod half-tandem suspension, tandem and tridem

	X			X	X	
--	---	--	--	---	---	--

### 7. Pneumatic suspension

	X			X	X	
--	---	--	--	---	---	--

### 8. Springs drawbar

	X			X	X	
--	---	--	--	---	---	--

## **8 TYRES AND WHEELS**

### **8.1 Tyre and wheel maintenance.**

Maintenance of correct inflation pressure is the basic essential factor in obtaining the best performance and life from a pneumatic tyre. The air inside the tyre enables it to carry a load. It is only when the inflation pressure is correctly matched that the tyre adopts its optimum cross-sectional shape and the tread rests correctly on the road surface with the correct pressure distribution across its whole width, thus allowing the sidewalls to provide the required degree of flexibility. Both performance and life of the tyres will suffer if pressures are unsuitable so both over or under inflation ( or overload which has the same effect ) are similarly undesirable.

**Underinflation** results in excessive deflection which increases the heat generated by the tyre, this in turn leads to its eventual disintegration. In addition the distortion of the casing will result in the lifting of the centre of the tread, thus overloading the outer edges of the tread, producing rapid wear at those points.

**Overinflation** distorts the tyre's casing, but in this case it tends to lift the outer edges of the tread off the road surface and imposes extra load and more rapid wear on the centre of the tread. Owing to reduced flexibility the tyre will be more vulnerable to impact damage, ride quality will be impaired and the wheels will be more liable to bounce which can result in skidding due to brakes locking.

Unlike cars on which tyre loads do not vary greatly it is not practicable to provide standard recommendations. This is because tyre loading and operating conditions vary widely.

Remember that spreaders travel laden one way and unladen in the opposite direction, it is therefore desirable to establish a suitable mean pressure that minimises both under inflation when loaded and excessive over inflation when running light.

### **Road usage**

**Max gross combination weight is 24390Kg and maximum gross spreader weight is 18290kg.**

**If your machine is wider then 2.55m and up to 3.5m your maximum speed is 20 mph, above 3.5m is 12 mph.**

## 8.2 PRESSURE SETTINGS STD TYRES - GENERAL

TYRE TYPE	6 MPH/10 KPH - Bar/PSI						12 MPH/20 KPH - Bar/PSI			
	10000 kg	13000 kg	15000 kg	17000 kg	18000 kg	20000 kg	10000 kg	10170 kg	15000 kg	20000 kg
16.9-14 x 34 P14	2.8/41						2.5/36			
18.4 x 34 PR14		3.0/44					3.0/44			
18.4 x 38 T-347		2.9/43						3.0/44		
580/70 R38			2.0/29	2.5/36	2.8/41	3.0/44		2.0/29		
710/70 R38			2.0/29	2.0/29	2.3/33	2.5/36		1.7/25		

Recommended rims in red

For stationary service (0 km/h) and speed up to 10 km/h inflation pressure must increase by 20%. Field dual: 88% of field load, field triple: of field load.

Alliance allows for free rolling application: Load capacity to be increased by 15%, after increasing the inflation pressure by 20%.

### STANDARD TYRES 16.9-14 x 34 P14

Size	Rim	Unloaded dimension		Loaded Static Radius	Rolling Circum	P.R.Stars Load Index	S.F. pressure	Recommended load, kg (lbs)																		
		SW	OD					Speed, km/h (mph)																		
								Not high and sustained long-term transport								Field operation										
				mm in	mm in	mm in	mm in	Speed Symbol	Bar psi	Static	10 6	15 12	20 15	25 19	30 23	35 27	40 31	45 35	50 39	55 43	60 47					
16.9-14	W15 D1014	429 16.9	558 22.0	725 28.5	4716 186.7	1	1.3 18.8	4878 10800	2668 5870	2188 4820	1890 4160	1778 3900	1618 3550	1488 3260	1328 2920	1188 2610	1068 2330	968 2110	888 1930							
								13 8880	5660	4800	4180	3800	3550	3460	3470	3460	3460	3460	3460	3460	3460	3460	3460	3460	3460	
								1.2	4528 2968	2428 2118	1978 1798	1798 2788	2388 2118	1978 2788	2388 2118	1978 2788	2388 2118	1978 2788	2388 2118	1978 2788	2388 2118	1978 2788	2388 2118	1978 2788	2388 2118	1978 2788
									17 8880	6520 5330	4650 4340	3940 3690	3590 3290	3290 2990	2990 2690	2690 2390	2390 2090	2090 1790	1790 1490	1490 1190	1190 890	890 590	590 290	290 0	0 0	0 0
								1.3	4748 3098	2538 2268	2068 1878	1868 1868	1868 1868	1868 1868	1868 1868	1868 1868	1868 1868	1868 1868	1868 1868	1868 1868	1868 1868	1868 1868	1868 1868	1868 1868	1868 1868	1868 1868
									19 10440	6810 5570	4850 4540	4120 3840	3690 3490	3290 3090	2890 2690	2490 2290	2090 1890	1690 1490	1290 1090	890 690	490 290	0 0	0 0	0 0	0 0	
						SFR 135A2		1.5	6208 3398	2788 2428	2268 2068	2068 1968	1968 1968	1968 1968	1968 1968	1968 1968	1968 1968	1968 1968	1968 1968	1968 1968	1968 1968	1968 1968	1968 1968	1968 1968	1968 1968	1968 1968
								22 11450	7470 6120	5330 4980	4540 4340	3890 3690	3490 3290	3090 2890	2690 2490	2290 2090	1890 1690	1490 1290	1090 890	690 490	290 0	0 0	0 0	0 0	0 0	
								1.6	6418 3538	2898 2538	2368 2168	2168 2068	2068 2068	2068 2068	2068 2068	2068 2068	2068 2068	2068 2068	2068 2068	2068 2068	2068 2068	2068 2068	2068 2068	2068 2068	2068 2068	2068 2068
								23 11820	7780 6370	5530 5180	4710 4510	4060 3860	3660 3460	3260 3060	2860 2660	2460 2260	2060 1860	1660 1460	1260 1060	860 660	460 260	0 0	0 0	0 0	0 0	
								1.7	6598 3668	2998 2638	2468 2268	2268 2168	2168 2168	2168 2168	2168 2168	2168 2168	2168 2168	2168 2168	2168 2168	2168 2168	2168 2168	2168 2168	2168 2168	2168 2168	2168 2168	2168 2168
								25 12310	8040 6590	5720 5350	4870 4620	4220 4020	3620 3420	3220 3020	2820 2620	2420 2220	2020 1820	1620 1420	1220 1020	820 620	420 220	0 0	0 0	0 0	0 0	
						SFR 142A2		1.8	6738 3748	3068 2668	2498 2298	2298 2198	2198 2198	2198 2198	2198 2198	2198 2198	2198 2198	2198 2198	2198 2198	2198 2198	2198 2198	2198 2198	2198 2198	2198 2198	2198 2198	2198 2198
								26 12620	8240 6740	5860 5490	5000 4790	4390 4190	3790 3590	3390 3190	2990 2790	2590 2390	2190 1990	1790 1590	1390 1190	990 790	590 390	190 0	0 0	0 0	0 0	
								1.9	6918 3868	3168 2768	2598 2398	2398 2298	2298 2298	2298 2298	2298 2298	2298 2298	2298 2298	2298 2298	2298 2298	2298 2298	2298 2298	2298 2298	2298 2298	2298 2298	2298 2298	2298 2298
								28 13020	8500 6960	6060 5690	5150 4950	4450 4250	3850 3650	3450 3250	3050 2850	2650 2450	2250 2050	1850 1650	1450 1250	1050 850	650 450	250 0	0 0	0 0	0 0	
								2	6998 3988	3268 2868	2698 2498	2498 2398	2398 2398	2398 2398	2398 2398	2398 2398	2398 2398	2398 2398	2398 2398	2398 2398	2398 2398	2398 2398	2398 2398	2398 2398	2398 2398	2398 2398
								29 13440	8770 7180	6260 5890	5310 5110	4610 4410	4010 3810	3610 3410	3210 3010	2810 2610	2410 2210	2010 1810	1610 1410	1210 1010	810 610	410 210	0 0	0 0	0 0	
						SFR 143A2		2.2	6498 4258	3478 3028	2828 2678	2678 2568	2568 2568	2568 2568	2568 2568	2568 2568	2568 2568	2568 2568	2568 2568	2568 2568	2568 2568	2568 2568	2568 2568	2568 2568	2568 2568	2568 2568
								32 14300	9320 7640	6650 6210	5680 5480	4880 4680	4280 4080	3680 3480	3280 3080	2880 2680	2480 2280	2080 1880	1680 1480	1280 1080	880 680	480 280	0 0	0 0	0 0	
								2.5	6998 4568	3748 3258	3048 2778	2778 2668	2668 2668	2668 2668	2668 2668	2668 2668	2668 2668	2668 2668	2668 2668	2668 2668	2668 2668	2668 2668	2668 2668	2668 2668	2668 2668	2668 2668
								36 15400	10040 8240	7160 6720	6120 5920	5320 5120	4520 4320	3920 3720	3520 3320	3120 2920	2720 2520	2320 2120	1920 1720	1520 1320	1120 920	720 520	320 120	0 0	0 0	
								2.8	7488 4888	4008 3488	3258 2968	2968 2858	2858 2858	2858 2858	2858 2858	2858 2858	2858 2858	2858 2858	2858 2858	2858 2858	2858 2858	2858 2858	2858 2858	2858 2858	2858 2858	2858 2858
								41 16480	10750 8810	7670 7180	6520 6320	5520 5320	4720 4520	4120 3920	3720 3520	3320 3120	2920 2720	2520 2320	2120 1920	1720 1520	1320 1120	920 720	520 320	120 0	0 0	



# LOWLANDER MK4 MANURE SPREADER – INSTRUCTION & SPARES MANUAL


## 18.4 x 34 PR14

Size	Rim	Unloaded dimension		Loaded Static Radius	Rolling Circum	PR Stars Load Index	H/S, g/rev	Recommend load, kg (lbs)											
		SW	OD					Speed, km/h (mph)											
								Not high and sustained torque, Road transport										Field operation	
																		Low Torque	High Torque
mm in	mm in	mm in	mm in	Speed Symbol	Bar psi	Static	10 8	20 12	30 19	40 25	50 31	10 8	20 12	10 8					
18.4-34	W16L 20P18 W16L	457 18.4	1600 65	748 29.4	4882 192.2	6PR 137A8	6.9	4720	3880	2620	2190	2050	1870	2570	2460	2190			
							13	10400	8780	5550	4820	4520	4120	6320	5420	4820			
							1	5010	3270	2680	2320	2180	1980	3050	2620	2320			
							15	11240	7200	5600	5130	4800	4560	6720	5770	5130			
							1.1	5290	3450	2830	2480	2300	2090	3220	2790	2480			
							16	11650	7600	6230	5420	5070	4600	7090	6080	5420			
						8PR 142A8	1.2	5570	3630	2980	2590	2420	2280	3290	2900	2590			
							17	12270	8000	6560	5700	5330	4850	7470	6390	5700			
							1.3	5840	3810	3120	2720	2540	2310	3560	3080	2720			
							19	12860	8390	6870	5990	5590	5090	7940	6720	5990			
							1.4	6100	3980	3260	2840	2660	2410	3710	3180	2840			
							20	13440	8770	7180	6260	5840	5310	8170	7000	6260			
						10PR 146A8	1.5	6210	4050	3320	2890	2790	2480	3780	3240	2890			
							22	13680	8920	7310	6370	5930	5420	8330	7140	6370			
							1.7	6470	4330	3670	3190	2990	2640	4000	3480	3190			
							25	14690	9590	7860	6830	6390	5810	8940	7670	6830			
							1.8	6900	4500	3690	3210	3080	2730	4200	3680	3210			
							26	15200	9910	8130	7070	6610	6010	9250	7930	7070			
						14PR 153A8	2	7500	4820	3950	3430	3210	2920	4490	3880	3430			
							29	16260	10620	8700	7560	7070	6430	9890	8480	7560			
							2.3	8000	5220	4280	3720	3480	3170	4870	4180	3720			
							33	17620	11500	9430	8180	7670	6980	10730	9210	8180			
							2.8	9400	5480	4490	3910	3650	3320	5110	4380	3910			
							36	18500	12070	9890	8610	8040	7310	11260	9650	8610			



## 580/70 R38 STANDARD 170/A8 HIGH LOAD 180/A8

Size	Rim	Unloaded dimension		Loaded Static Radius	Rolling Circum	PR Stars Load Index	H/S, g/rev	Recommend load, kg (BA)											
		SW	OD					Speed, km/h (mph)											
								Not high and sustained torque, Road transport								Field operation			
																Low Torque		High Tor	
mm in	mm in	mm in	mm in	Speed Symbol	Bar psi	Static	10 E	25 10	30 19	40 25	50 34	10 E	20 12	30 19					
580/70R38	W16A	577 22.7	1817 71.5	816 32.1	5343 218.4	155A8 152 B	1	6780	4810	3260	2830	2640	2480	4120	3630	3160			
							15	14890	9710	7180	6340	6430	5900	9070	7780	6940			
							1.3	7090	5160	3610	3070	2830	2620	4300	4120	3670			
							19	17380	11240	8390	6980	7560	6670	10570	9070	8080			
							1.8	8910	5810	4300	4150	3870	3630	5430	4650	4150			
							22	19430	12800	9470	8140	8540	7780	11980	10240	9140			
						Reinforced rim 170A8 167 B	2	11340	7400	5470	5280	4930	4490	6900	5820	5280			
							29	24980	16300	12050	11630	10860	9890	15200	13040	11630			
							2.4	12600	8220	6000	5800	5480	4990	7670	6580	5800			
							35	27730	18110	13290	12910	12070	10980	16890	14490	12910			
							2.8	13800	9000	6660	6420	6090	5480	8400	7200	6420			
							41	30400	19820	14670	14140	13230	12030	18500	15860	14140			
						Reinforced rim 180A8	2.2	14880	9710	7180	6340	6430	5900	9070	7780	6940			
							46	32780	21390	15810	15240	14250	12970	19960	17090	15240			
							3.6	15940	10400	7690	7420	6930	6310	9700	8320	7420			
							52	35110	22910	16940	16340	15260	13900	21370	18330	16340			
							4	16850	11660	8160	7890	7370	6710	10320	8840	7890			
							56	37330	24380	18020	17380	16230	14780	22730	19470	17380			
							4.4	17920	11680	8660	8340	7790	7090	10918	9360	8340			
							64	39470	25750	19050	18370	17190	15620	24030	20590	18370			
							4.8	18400	12000	8880	8680	8090	7280	11200	9680	8680			
							67	40530	26430	19560	18850	17620	16040	24670	21150	18850			



# LOWLANDER MK4 MANURE SPREADER – INSTRUCTION & SPARES MANUAL

## 710/70 R38

Size	Rim	Unloaded dimension		Loaded Static Radius	Rolling Circum	PR,Stars Load Index	Infl. press	Recommend load, kg (lbs)								
		SW	OD					Speed, km/h (mph)								
								Not high and sustained torque; Road transport								
				Low Torque	High Tor											
mm in	mm in	mm in	mm in	Speed Symbol	Bar psi	Static	10 6	25 16	30 19	40 25	50 31	10 6	20 12	10 6		
710/70R38	DW23A	716 28.2	1948 76.7	877 34.5	5739 225.9	166A8 163B	1.3 19	10790 23770	7040 15510	5210 11480	5020 11060	4690 10330	4270 9410	6570 14470	5630 12400	5020 11060
							1.5 22	11730 25840	7650 16850	5660 12470	5460 12030	5100 11230	4640 10220	7140 15730	6120 13480	5460 12030
							1.6 23	12190 26850	7950 17510	5880 12950	5670 12490	5300 11670	4820 10620	7420 16340	360 14010	5670 12490
						172A8 169B	1.7 25	12810 28220	360 18410	6180 13610	5960 13130	5570 12270	5070 11170	7800 17180	6680 14710	5960 13130
							1.9 28	13660 30090	8910 19630	6590 14520	360 14010	5940 13080	5410 11920	8320 18330	7130 15700	360 14010
							2.1 30	14490 31920	9450 20810	6990 15400	6740 14850	6300 13880	5730 12620	8820 19430	7560 16650	6740 14850
		178A8 175B	2.2 32	14970 32970	9770 21520	7230 15930	6970 15350	6510 14340	5920 13040	9110 20070	7810 17200	6970 15350				
			2.5 36	16150 35570	10530 23190	7790 17160	7510 16540	7020 15460	6390 14070	9830 21650	8420 18550	7510 16540				
			2.8 41	17250 38000	11250 24780	8330 18350	8030 17690	7500 16520	6830 15040	10500 23130	9000 19820	8030 17690				

## OPTION TYRES


## 520/70 R34

Size	Rim	Unloaded dimension		Loaded Static Radius	Rolling Circum	PR,Stars Load Index	Infl. press	Recommend load, kg (lbs)									
		Speed, km/h (mph)															
		SW	OD					Not high and sustained torque; Road transport						Field operation			
										Low Torque	High Tor						
		mm in	mm in	mm in	mm in	Speed Symbol	Bar psi	Static	10 6	25 16	30 19	40 25	50 31	10 6	20 12	10 6	
520/70R34	W16L W18L W18L	516 20.3	1632 64.3	739 29.1	4826 190	148A8 145 B	1	5500	3590	2650	2560	2390	2170	3350	2870	2560	
							15	12110	7910	5840	5640	5260	4780	7380	6320	5640	
							1.3	6420	4190	3100	2990	2790	2540	3910	3350	2990	
						19	14140	9230	6830	6590	6150	5590	8610	7380	6590		
						1.6	7250	4730	3500	3370	3150	2870	4410	3780	3370		
						23	15970	10420	7710	7420	6940	6320	9710	8330	7420		
		168A8 165 B	3.5	11270	7350	5440	5240	4900	4460	6860	5880	5240					
			51	24820	16190	11980	11540	10790	9820	15110	12950	11540					
			4	12190	7950	5880	5670	5300	4820	7420	6360	5670					
			58	26850	17510	12950	12490	11670	10620	16340	14010	12490					
			4.4	12880	8400	6220	5990	5600	5100	7840	6720	5990					
			64	28370	18500	13700	13190	12330	11230	17270	14800	13190					

# LOWLANDER MK4 MANURE SPREADER – INSTRUCTION & SPARES MANUAL

## 18.4 x 38 T347 Cross ply only

Size	Rim	Unloaded dimension		Loaded Static Radius	Rolling Circum	PR,Stars Load Index	Infl. press	Recommend load, kg (lbs)								
		Speed, km/h (mph)														
		Not high and sustained torque, Road transport									Field operation					
											Low Torque	High Tor				
SW	OD	mm in	mm in	mm in	mm in	Speed Symbol	Bar psi	Static	10 6	20 12	30 19	40 25	50 31	10 6	20 12	10 6
18.4-38	DW16 W16L W15L	467 18.4	1750 68.9	795 31.3	5185 204.1	8PR 143A8	1.2	5730	3740	3060	2660	2490	2270	3490	2990	2660
							17	12620	8240	6740	5860	5480	5000	7690	6590	5860
							1.3	6000	3920	3210	2790	2610	2380	3650	3130	2790
							19	13220	8630	7070	6150	5750	5240	8040	6890	6150
							1.4	6270	4090	3350	2920	2725	2480	3820	3270	2920
							20	13810	9010	7380	6430	6000	5460	8410	7200	6430
						10PR 148A8	1.5	6510	4250	3480	3030	2830	2580	3960	3400	3030
							22	14340	9360	7670	6670	6230	5680	8720	7490	6670
							1.6	6760	4410	3620	3150	2940	2680	4120	3530	3150
							23	14890	9710	7970	6940	6480	5900	9070	7780	6940
							1.8	7250	4730	3870	3370	3150	2870	4410	3780	3370
							26	15970	10420	8520	7420	6940	6320	9710	8330	7420
						14PR 155A8	2.1	8050	5250	4310	3750	3500	3190	4900	4200	3750
							30	17730	11560	9490	8260	7710	7030	10790	9250	8260
							2.3	8490	5540	4540	3950	3690	3360	5170	4430	3950
							33	18700	12200	10000	8700	8130	7400	11390	9760	8700
							2.5	8910	5810	4770	4150	3875	3530	5430	4650	4150
							36	19630	12800	10510	9140	8540	7780	11960	10240	9140



## 420/85 R34

Size	Rim	Unloaded dimension		Loaded Static Radius	Rolling Circum	PR, Stars Load Index	Infl. press	Recommend load, kg (lbs)									
		Speed, km/h (mph)						Not high and sustained torque; Road transport				Field operation					
												Low Torque	High Tor				
		SW	OD									Static	10 6	20 12	30 19	40 25	50 31
mm in	mm in	mm in	mm in	Speed Symbol	Bar psi												
420/85R34	W15L W14L W13	450 17.7	1580 62.2	713 28.1	4696 184.9	139D 142A8	0.8	3730	2430	1990	1860	1770	1770	1620	2480	2120	1890
							12	8220	5350	4380	4100	3900	3900	3570	5460	4670	4160
							1	4260	2780	2280	2130	2030	2030	1850	2840	2440	2170
							15	9380	6120	5020	4690	4470	4470	4070	6260	5370	4780
							1.3	4950	3230	2640	2470	2350	2350	2150	3290	2820	2510
							19	10900	7110	5810	5440	5180	5180	4740	7250	6210	5530
						144D 147A8	1.6	5590	3650	2990	2790	2650	2650	2430	3710	3180	2840
							23	12310	8040	6590	6150	5840	5840	5350	8170	7000	6260
							1.8	5890	3840	3150	2940	2800	2800	2560	3920	3360	3000
							26	12970	8460	6940	6480	6170	6170	5640	8630	7400	6610
							2.1	6440	4200	3440	3220	3075	3075	2800	4310	3690	3290
							30	14190	9250	7580	7090	6770	6770	6170	9490	8130	7250



### 23.1-26

Size	Rim	Unloaded dimension		Loaded Static Radius	Rolling Circum	PR, Stars Load Index	Infl. press	Recommend load, kg (lbs)									
		SW	OD					Speed, km/h (mph)									
								Not high and sustained torque, Road transport								Field operation	
												Low Torque	High Tor				
mm in	mm in	mm in	mm in	Speed Symbol	Bar psi	Static	10 6	20 12	30 19	40 25	50 31	10 6	20 12	10 6			
23.1-26	DW20	587 23.1	1605 63.2	793 27.7	4648 183	8PR 14548	0.9 13	6930 15060	3870 8520	3170 6980	2860 6300	2580 5680	2360 5180	3610 7950	3100 6830	2760 6080	
							1 15	6300 13880	4110 9050	3370 7420	3040 6700	2740 6040	2490 5480	3840 8460	3290 7250	2930 6450	
							1.1 16	6670 14690	4360 9580	3570 7860	3100 6830	2900 6360	2640 5810	4060 8940	3480 7670	3100 6830	
							1.2 17	6830 15040	4460 9820	3660 8040	3300 7270	2970 6540	2700 5950	4160 9160	3560 7840	3180 7000	
							1.4 20	7480 16480	4880 10750	4000 8810	3480 7670	3260 7160	2960 6520	4560 10020	3900 8590	3480 7670	
							1.5 22	7880 17180	5090 11210	4170 9190	3760 8280	3390 7470	3080 6780	4750 10460	4070 8960	3630 8000	
						10PR 14948	1.7 25	8480 18500	5480 12070	4490 9890	3910 8610	3660 8040	3320 7310	5110 11260	4380 9650	3910 8610	
							1.8 26	8660 19050	5640 12420	4620 10180	4170 9190	3760 8280	3420 7530	5260 11590	4510 9920	4020 8800	
							1.9 28	8920 19650	5820 12820	4770 10510	4310 9490	3880 8590	3530 7780	5430 11960	4680 10260	4150 9140	
							2 29	9280 20260	6000 13220	4920 10840	4380 9430	4000 8810	3640 8020	5600 12330	4800 10570	4280 9430	
						12PR 15348	1.8 26	8720 19210	5690 12530	4660 10260	4090 8940	3790 8350	3480 7600	5310 11700	4550 10020	4060 8940	
							2 29	9270 20420	6050 13330	4960 10930	4310 9490	4030 8880	3670 8080	5640 12420	4840 10660	4310 9490	
							2.3 33	10060 22160	6560 14450	5380 11850	4690 10310	4375 9640	3980 8770	6130 13500	5250 11560	4680 10310	
							33	22160	14450	11850	10310	9640	8770	13500	11560	10310	





# LOWLANDER MK4 MANURE SPREADER – INSTRUCTION & SPARES MANUAL

## 620/70 R38 MICHELIN

620/70 R38 170A8/170B TL MEGAXBIB

MSPN : 99512

CAI : 476088

Load per tire (single)						Pressure	
30 mph	25 mph	20 mph	15 mph	6 mph	6 mph Cyl		
50 km/h	40 km/h	30 km/h	25 km/h	10 km/h	10 km/h Cyl		
7 390 lbs	7 390 lbs	7 890 lbs	8 160 lbs	10 050 lbs	11 050 lbs	1.0 bar	
3 350 kgs	3 350 kgs	3 580 kgs	3 710 kgs	4 560 kgs	5 010 kgs	1.0 bar	
7 910 lbs	7 910 lbs	8 470 lbs	8 770 lbs	10 750 lbs	11 860 lbs	1.2 bar	
3 590 kgs	3 590 kgs	3 840 kgs	3 980 kgs	4 875 kgs	5 360 kgs	1.2 bar	
8 980 lbs	8 980 lbs	9 600 lbs	9 950 lbs	12 150 lbs	13 490 lbs	2.3 psi	
4 075 kgs	4 075 kgs	4 355 kgs	4 515 kgs	5 510 kgs	6 120 kgs	1.6 bar	
10 040 lbs	10 040 lbs	10 740 lbs	11 130 lbs	13 550 lbs	15 130 lbs	2.8 psi	
4 555 kgs	4 555 kgs	4 870 kgs	5 050 kgs	6 145 kgs	6 865 kgs	2.0 bar	
11 100 lbs	11 100 lbs	11 870 lbs	12 310 lbs	14 950 lbs	16 770 lbs	3.5 psi	
5 035 kgs	5 035 kgs	5 385 kgs	5 585 kgs	6 780 kgs	7 605 kgs	2.4 bar	
12 170 lbs	12 170 lbs	13 020 lbs	13 900 lbs	16 350 lbs	18 400 lbs	4.1 psi	
5 520 kgs	5 520 kgs	5 905 kgs	6 125 kgs	7 415 kgs	8 345 kgs	2.8 bar	
13 230 lbs	13 230 lbs	14 150 lbs	14 680 lbs	17 750 lbs	20 040 lbs	4.8 psi	
6 000 kgs	6 000 kgs	6 420 kgs	6 660 kgs	8 050 kgs	9 090 kgs	3.2 bar	
				18 440 lbs	20 860 lbs	4.9 psi	
				8 365 kgs	9 460 kgs	3.4 bar	
				19 150 lbs	21 670 lbs	5.2 psi	
				8 685 kgs	9 830 kgs	3.6 bar	
				19 840 lbs	22 490 lbs	5.5 psi	
				9 000 kgs	10 200 kgs	3.8 bar	

## 710/70 R42

Size	Rim	Unloaded dimension		Loaded Static Radius	Rolling Circum	PR Stars Load Index	in ft press	Recommend load, kg (lbs)											
		SW	OO					Speed, km/h (mph)											
								Not high and sustained torque, Road transport										Field operation	
mm in	mm in	mm in	mm in	Speed Symbol	Bar psi	Static	10 6	25 16	30 19	40 25	50 31	10 6	20 12	10 6					
710/70R42 (Dens.365)	DW238	740 29.1	2055 80.3	936 36.9	6178 243.2	173A8 173 B	8.8	7870	5130	3800	3660	3420	3420	4790	4100	3660			
							12	17330	11300	8370	8060	7530	7530	10550	9030	8060			
							1	8950	5840	4328	4160	3890	3890	5450	4678	4160			
							15	19710	12860	9520	9160	8570	8570	12000	10290	9160			
							1.2	9960	6500	4810	4630	4330	4330	6060	5200	4630			
							17	21940	14320	10590	10200	9540	9540	13350	11450	10200			
							1.4	10900	7110	5268	5070	4740	4740	6640	5690	5070			
							20	24010	15660	11590	11170	10440	10440	14630	12530	11170			
							1.6	11800	7700	5690	5490	5150	5150	7180	6160	5490			
							23	25990	16960	12530	12090	11300	11300	15810	13570	12090			
							2	13430	8760	6480	6250	5840	5840	8180	7010	6250			
							29	29580	19300	14270	13770	12860	12860	18020	15440	13770			
							2.2	14210	9270	6860	6610	6180	6180	8650	7420	6610			
							30	31300	20420	15110	14560	13610	13610	19050	16340	14560			
							2.4	14950	9750	7220	6960	6500	6500	9180	7800	6960			
							35	32930	21480	15900	15330	14320	14320	20040	17180	15330			
						180A8 180B	2.6	16280	10620	7860	7580	7080	7080	9910	8500	7580			
							38	35860	23390	17310	16700	15590	15590	21830	18720	16700			
							2.8	17020	11100	8210	7920	7400	7400	10360	8880	7920			
							41	37490	24450	18080	17440	16300	16300	22820	19560	17440			
							3	17710	11550	8550	8240	7700	7700	10780	9240	8240			
							44	39070	25440	18830	18150	16960	16960	23740	20350	18150			
							3.2	18400	12000	8880	8560	8000	8000	11200	9600	8560			
							46	40530	26430	19560	18850	17620	17620	24670	21150	18850			

### 8.3 WHEEL TYPE & TORQUE SETTINGS


TYRE TYPE	WHEEL TYPE	WHEEL STUD TYPE & SIZE	TORQUE SETTINGS
16.9-14 x 34 P14	DW 16x34 centre nave 220 bore	8 x M18 - 1.5 275 PCD	270 Nm/200 lb/ft
18.4 x 34 PR14	16 x 34 centre nave 280 bore	10 x M22 - 1.5 335 PCD	510 Nm/375 lb/ft
18.4 x 38 PR14	DW 16x38 centre nave 281 bore	10 x M22 - 1.5 335 PCD	450 Nm/330 lb/ft
580/70 R38	W18A x 38 - 45 offset 280 bore	10 x M22 - 1.5 335 PCD	510 Nm/375 lb/ft
710/70 R38	DW 23a x 38 - 50 offset 280 bore	10 x M22 - 1.5 335 PCD	510 Nm/375 lb/ft

#### **IMPORTANT**

**CHECK WHEEL NUT TORQUE AFTER EACH LOAD FOR THE 1<sup>ST</sup> 10 LOADS AND THEN DAILY FOR THE FIRST WEEK AND ONCE A WEEK THEREAFTER.**


## 9. OPTIONS

### 9.1 SPRUNG DRAWBAR – OPTIONAL



KEY	QTY	PART No.	DESCRIPTION
1	1	70440	GUDGEON PIN & NUT
2	2	70442/2	PIVOT PIN
3	1	73102	NUT & BOLT M16
4	1	N/A	DRAWBAR TO SUIT MODEL
5	2	70438/1	SPRING 13 LEAF
6	3	70439/2	U-BOLT 30mm

## 9.2 REAR CLEVIS DRAWBAR - OPTIONAL




KEY	QTY	PART No.	DESCRIPTION
1	1	B5310	REAR CLEVIS DRAWBAR CROSS MEMBER
2	1	70107	7 PIN LIGHT SOCKET
3	1	51569	HYDRAULIC BRAKE CONNECTION
4	1	CF350932	AIR COUPLING MALE
5	1	CF351543	AIR COUPLING FEMALE

### NOTE:

The rear clevis drawbar is designed for highway use **only** towing an unladen spreader.




### 9.3 GUILLOTINE SLURRY DOOR




KEY	QTY	PART No.	DESCRIPTION
1	1	B4110	DOOR - 75/90
	1	B4112	DOOR - 105/105C/120/150/150C
	1	B4115	DOOR WITH WB AUGERS
2	2	B4136	50/35 1321 STROKE RAM - 75/90
	2	B4138	50/35 1626 STROKE RAM - 105/105C/120/150
3		65520	SEAL KIT D/A 50x35
4	2	B4130	TOP RAM PIN DIA 5/8"
5	2	B4132	BOTTOM RAM PIN DIA 3/4"
6	1	B4158	RUBBER SEAL
	1	B4184	CLAMPING STRIP & M8 x 35 BOLT C/W S.L NUTS
7	1	B4188	CLAMPING STRIP WITH W.B AUGERS
8	4	51590	3/8" BONDED SEAL
9	2	51335	3/8" M/M ADAPTOR
10	2	10522	3/8" x 1/8" RESTRICTOR
11	8	50988	SPLIT PIN

#### 9.4 GUILLOTINE SLURRY DOOR HORIZONTAL BEATER



KEY	QTY	PART No.	DESCRIPTION
1	1	B4113	DOOR - 105/120/150 HB
	2	B4138	RAM
3		65520	SEAL KIT D/A 50x35
4	2	B4130	TOP RAM PIN DIA 5/8"
5	2	B4132	BOTTOM RAM PIN DIA 3/4"
6	1	B4158	RUBBER SEAL
	1	B4166	RUBBER SEAL WITH WB AUGERS
7	1	B4184	CLAMPING STRIP & M8 x 35 BOLT C/W S.L NUTS
8	4	51590	3/8" BONDED SEAL
9	2	51335	3/8" M/M ADAPTOR
10	2	10522	3/8" x 1/8" RESTRICTOR
11	8	50988	SPLIT PIN

## 9.5 GUILLOTINE SLURRY DOOR HYDRAULIC CIRCUIT.




KEY	QTY	PART No.	DESCRIPTION
1	2	51576	1/2" PROBE MALE SELF SEALER
2	2	51583	DUMMY 1/2" FEMALE
3	2	51463	3/8"-3/8"- BPT BULKHEAD
4	2	51447	3/8"-3/8"-3/8" MALE TEE
5	2	51335	3/8"-3/8" BPT NIPPLE
6	2	10522	3/8"-3/8" BPT NIPPLE 1/8" REDUCED
7	4	51590	DIA 3/8" DOWTY WASHER
8	2	51591	DIA 1/2" DOWTY WASHER
9	2	52316	HOSE END DIA 3/8-1/2" BPT MALE
10	8	52311	HOSE END DIA 3/8"-3/8" BPT FEMALE
11	6	52313	HOSE END DIA 3/8"-3/8" BPT 90 DEG FEM
12	2		HOSE 3/8" BORE 2 WIRE x 2500
13	2		HOSE 3/8" BORE 2 WIRE x 305
14	4		HOSE 3/8" BORE 2 WIRE x LENGTH
16	REF	SEE NOTE	HYD RAM 50mm BORE DOUBLE ACTING


Note: 75 and 105C are the same and so are the 90 & 150C.

**9.6 SUPPORT LEG PART No. 70307**


Use unladen only



**9.7 TOOLBOX PART No. 80136**




## 9.8 SLUDGE CAKE OPTION WIDEBODY



KEY	QTY	PART No.	DESCRIPTION
1	2	B1159/1	BEARING CAP
2	2	B2352	SPACER
3	8	73155&73375	BOLT AND LOCKNUT
4	2	B1180/1	BEARING M60
5	1		SLUDGE CAKE BODY
6	1	B1048	AUGER ASSEMBLY LH
7	1	B1049	AUGER ASSEMBLY RH
8	80	B1101/B	CUTTER POINT BORON
9	8	B1123	AUGER BLADE L.H BORON (6 HOLE)
10	1	B3180	AUGER GEARBOX
	160	B1101/1	BOLT AND LOCKNUT (BOLTS FOR CUTTER)
11	24	B1104	BOLTS FOR BLADES


## 9.9 DETACHABLE SPINNER DECK – ADD ON OPTION



## 9.9 DETACHABLE SPINNER DECK – ADD ON OPTION PARTS LIST

KEY	QTY	PART No.	DESCRIPTION
1	2	B8810	BUCKET HOOK
2	1	AMS0142	REAR CANOPY ASSEMBLY
3	3	DMS0889	LINK CANOPY
4	2	DMS0322	END CAP
5	2	AMS0141	MOUNTING FLANGE ASSEMBLY
6	8	B1116	AUGER/SPINNER BLADE
7	4	B8354/B8355	BLADE HOLDER ASSEMBLY
8	1	B8340	SPINNER DISC LH
9	1	B8342	SPINNER DISC RH
10	1	B3190	BERMA SRT 18/1830 1000/520 3IN1
11	1	DMS0513	RUBBER SKIRT
12	2	DMS0512	CLAMPING STRIP
13	1	DMS0511	CLAMPING STRIP
14	2	A2134	HOOK BOLT
15	4	DMS0072	HINGE TUBE
16	20		M12 LOCK NUT
17	4		M12 WASHER
18	4		M12 BOLT x 70mm
19	2		M10 BOLT x 70mm
20	2		M10 LOCK NUT
21	8		M8 LOCK NUT
22	8		M8 LOCK NUT
23	8		M16 LOCK NUT
24	8		M16 BOLT x 45mm
25	16		M12 BOLT x 50mm
26	16		M14 LOCK NUT
27	16		M14 BOLT x 50
28	16		M14 WASHER
29	2	B8336	DISC DRIVE FLANGE
30	2	B8339	FLANGE CAP
31	2	73698	CAP SCREW
32	1	B8484	FLEXIDRIVE BODY
33	1	B8486	FLEXIDRIVE
34	6	B1142	RUBBER DRIVE BLOCK
35	6	B1142	RUBBER DRIVE BLOCK

### 9.10 HANDBRAKE CONTROL MULTI-STROKE MS45 PART No. 70321




### 9.11 BODY SEAL RUBBERS


KEY	QTY	PART No.	DESCRIPTION
1	1	B4158	SLURRY DOOR & FRONTWALL MK4
2	1	B4160	AUGER DECK MK4
3	1	B4173	DOUBLE WIPE MK4
4	1	B4166	SLURRY DOOR & FRONTWALL WB
5	1	B4175	DOUBLE WIPE WB
6	1	B4171	HORIZONTAL BEATER CANOPY MK4
7	1	B4172	HORIZONTAL TOP WIPE MK4



## 9.12 SIMPLE CANOPY




## 9.13 HYDRAULIC BORDER CONTROL



KEY	QTY	PART No.	DESCRIPTION
1	1	65078	RAM DA30 20 255
2	1	B4191	MOUNT BRACKET LH
2	1	B4191/1	MOUNT BRACKET RH
3	1	B4190	DEFLECTOR PLATE LH
3	1	B4190/1	DEFLECTOR PLATE RH
		65505	30/20 SEAL KIT


#### 9.14 AUTO REAR LAMPS



<b>KEY</b>	<b>QTY</b>	<b>PART No.</b>	<b>DESCRIPTION</b>
	1	B5232	AUTO LAMP COVER COMPLETE ASSEMBLY
1	2	70081	TRIANGLE
2	2	70009/3	REAR LAMP
3	2	DMS2256-1/-2	LAMP BRACKET LH / RH
4	2	AMS1336-1/-2	LAMP COVER LH / RH
5	2	DMS2254	POST GUIDE
6	2	DMS225	STRIKER PLATE

### 9.15 MANUAL REAR LAMPS COVERS

Manual rear lamp covers fitted when slurry door is not fitted.



## 9.16 WEIGH CELL SPARES – GRIFFITH ELDER



Weigh cell

B2960



Junction box

95-0385



Weigh cell display / head unit

B9051



Mount arm & ball mount 15-0175 & 15-0176



Proximity sensor & 10m cable

B9058



Signal cable fem lock 3m

B9056



Switch cable 8m

B9053



Power cable fem lock 3m

B9052



Signal cable fem lock 1m

B9055




Signal cable fem lock 7m

B9054

## 10. ELECTRICS

### 10.1 WIRING FOR 12v 7 PIN PLUG



- 1) YELLOW –Y– L.H. INDICATOR
- 2) BLUE –B– FOG
- 3) WHITE –W– EARTH
- 4) GREEN – G- R.H. INDICATOR
- 5) BROWN –BR- TAIL
- 6) RED –R- STOP
- 7) BLACK –BL- SIDE MARKERS

Pins 5 & 7 may be linked.

#### FOR NORTH AMERICAN UNITS / COMMERICAL PLUG

- 1) WHITE (EARTH) – R- STOP
- 2) BLACK – G – R.H. INDICATOR
- 3) YELLOW – BR – TAIL
- 4) RED – W – EARTH
- 5) GREEN – BL – SIDEMARKERS
- 6) BROWN – Y – L.H. INDICATOR
- 7) BLUE – B - FOG

## **10.2 REAR LAMPS – 70009/3 3 Spade connector type**



## **10.3 FRONT MARKER LAMP - 70154**



## **HEALTH AND SAFETY & POTENTIAL HAZARDS**

### **11.1 Hazardous machinery warning**

This machine is hazardous if improperly used and may cause serious injury or death if not used in accordance with these operating instructions and safety warnings. Employers are required to train and supervise all operators and assistants to observe safety precautions described by this handbook, the installation process and by warning decals.

### **11.2 Loss of control**

Overloading, excessive speed or use on excessive slopes may result in loss of control. The towing tractor must be suitable for the trailer weight and other operating conditions. Trailer brakes must be used at all times. The balance of the spreader can be affected by the load lowering during spreading.

### **11.3 Operation around bystanders**

Do not operate this machine in proximity to bystanders who may be injured by projectiles or other functions including being run over or entangled in the auger.

### **11.4 Hydraulic fluid penetration or burning**

Operators must be trained to avoid risks relating to the possibility of hydraulic fluid penetration resulting from high pressure fluid sprays directly contacting an operators skin. Hydraulic components may also be hot and may cause burning if touched.

### **11.5 Electrocutation**

An operator or a bystander could be electrocuted if the guillotine door was raised where there is a possibility of contact with overhead electrical wires.

### **11.6 Body entry**

A person must not enter the body while the machine is running. Care must be taken to avoid slip/fall injuries while entering the body.

### **11.7 Coupling / Decoupling**

Care must be taken to avoid crushing an assistant when coupling or decoupling the machine to a tractor.

### **11.8 Machinery start up**

Sound the horn before starting this machine.

### **11.9 Machinery shut down**

This machine must be operated from a tractor driver's seat. The tractor and machine must be shut down, the key removed and hydraulics lowered, if the driver leaves the seat or before any adjustments or repairs are made.

### **11.10 Additional driver protection**

Extra protection can be achieved by lowering the slurry door as the load decreases in height.

### **11.11 PTO Connection and guarding**

Improper PTO connection and operation may cause machine failure and injury to an operator. PTO shaft guards must be used at all time. See DVD & PTO manual.

### **11.12 Personal protective equipment (PPE)**

When maintaining and operating this machine make sure appropriate PPE is worn. i.e. Overalls, gloves, safety shoes, eye and ear protection.

### **11.13 Safety decal location.**

- i) **Warning – When spreading , lower slurry door to cover exposed augers as the load reduces.**






ii) **Danger – Keep hands clear of taildoor and mechanism during operation.**



**11.14 Operating hazard area**

- Objects can be thrown out from the rotors with sufficient force to severely injure people. Stay away from machine when it is running. Keep others away.
- Stay out of shaded hazard area.
- Always know where all additional personnel are located when operating the spreader. Never allow anyone within the hazard area.
- Stay away from the sides and rear of the spreader when it is running to prevent being hit by flying debris. Rotors can expel solid objects with sufficient force to cause severe injury. Stay out of hazard area.



**NOTE:** Remember any foreign objects hidden in the material i.e. stones, bricks, wood etc. can be thrown further than the actual material, which could result in serious injury or loss of life.

### 11.15 WARNINGS



#### WARNING

Keep all limbs clear of the spreading augers when in motion. Do not attempt to remove obstacles or carry out adjustments without stopping spreader operation first and turning of the tractor engine off and removing the keys. Taking short cuts can result in permanent injury or loss of life.

**Before attempting to carry out any checks or adjustments disengage the PTO and stop the tractor engine and remove key.**

Guards are provided for your safety. **Never** operate the spreader with any removed or open.

Before engaging the PTO make sure that there is no person standing to the rear or side of the spreader. Please observe at all times during spreading operation that no person or persons are present within the working proximity. Remember any foreign objects hidden in the material i.e. stones, bricks, wood etc can be thrown further than the actual material, which could result in serious injury or loss of life.

#### HEALTH AND SAFETY EXECUTIVE

NEVER try to clear blockages from a PTO-driven machine while it is moving. Always:

- Disengage the power drive;
- Stop the tractor engine;
- Ensure controls are in neutral and the hand brake is applied;
- Remove the engine key;
- Wait for all movement to cease before attempting to clear any blockage and use a tool to clear the blockage.

### 12. WARRANTY

During the 3 year warranty period any failures which occur due to faulty components or workmanship must be reported to G.T. Bunning & Sons Ltd before any repairs or replacements of components is carried out. The warranty period commences on the despatch date from the factory. All parts not guaranteed by G.T. Bunning & Sons Ltd are covered by the component manufacturer and are subject to their own warranty. The warranty terms only apply to machines that have been subject to fair wear and tear operation and where routine maintenance has been carried out.

### 13. IMPORTANT INFORMATION

When using the spreader in conjunction with a tractor which has a fast and slow response control on the spool valves, check that the control on the spool valve is not in the slow position in respect of the floor drives, as this will over ride the variable floor speed.

The spreader always runs very quietly when working, if loud banging noises are heard this will mean that foreign objects are in the material. Obviously the shearbolt may well break. If the shearbolts on the PTO has not sheared and the noises persists **STOP THE SPREADER SWITCH OFF TRACTOR ENGINE** and check the spreader.

From new, it is strongly recommended that you do not use a high pressure cold washer and definatley not a hot pressure washer to the outside of the spreader for **12 weeks**. This will damage the paintwork whilst normal curing of the paint takes place. Careful low pressure washing is acceptable.

**Do not** let manure dry and set on fresh paint for the first 3-4 weeks. During this period it is advisable to clean the machine after use as instructed.

[illegible]

## 15. IDENTIFICATION PLATE

The machine number (VIN) is required with all orders for spare parts and technical enquires. This is necessary in order to ensure correct delivery of spare parts.

The identification plate with the machine number is attached to the middle right side of the machine drawbar.



## 16. TECHNICAL DATA & SPECIFICATIONS

	MODEL					
	75	90	105	105C	120	150
<b>GROSS DESIGN Kg</b>	12500	16000	17500	17500	18750	20750
<b>GROSS GB Kg</b>	12500	13170	13670	13670	13920	13920
<b>AXLE DESIGN Kg</b>	10000	13000	14000	14000	15000	17000
<b>AXLE GB Kg</b>	10000	10170	10170	10170	10170	10170
<b>EYE Kg</b>	2500	3000	3500	3500	3750	3750
<b>TARE WEIGHT Kg</b>	4000	4400	4900	4750	4950	5200
<b>PAYLOAD Kg</b>	7500	9000	10500	10500	12000	15000
<b>PAYLOAD + TARE Kg</b>	11500	13400	15400	15250	16950	20200

Bunning tolerance +/-2%

**NB – Machines with extension sides or build in flares are designed for use with light materials. DO NOT EXCEED THE PLATED WEIGHTS.**


### USE ON HIGHWAYS

Maximum gross combination weight is **24390 Kg**.

Maximum spreader weight is **18290 Kg**.

	MODEL					
	75	90	105	105C	120	150
<b>Axle</b>	Single	Single	Single	Single	Single	Single
<b>Axle beam size</b>	90mm	100mm	110mm	110mm	140mm	150mm
<b>Carrying capacity</b>	7500 Kg	9000 Kg	10500 Kg	10500 Kg	12000 Kg	15000 Kg
<b>Cubic meters level</b>	6.8m	8.6m	10.4m	9.6m	11.6	12.6
<b>Cubic meters heaped</b>	9.1m	11.4m	13.2m	12.9	14.6m	15.9m
<b>Extended capacity</b>	15.3m	18.6m	20.4m	N/A	22.2m	24.3m
<b>Body size (int.mm)</b>	4150x1500x1010	5150x1500x1010x	5150x1500x1230	4200x1500x1270	5450x1500x1290	5950x1500x1290
<b>Floor drive</b>	Hydraulic	Hydraulic	Hydraulic	Hydraulic	Hydraulic	Hydraulic
<b>Floor chain size</b>	16mm	16mm	16mm	16mm	16mm	16mm
<b>Brake size mm</b>	355x80	400x80	400x80	400x80	406x140	406
<b>Tyre size</b>	16.9x34 PR14	18.4x34 PR14	580/70 R38	580/70 R38	580/70 R38	580/70 R38
<b>Spread Mech</b>	Twin vertical augers	Twin vertical augers	Twin vertical augers	Twin vertical augers	Twin vertical augers	Twin vertical augers
<b>Spread width</b>	Up to 16m	Up to 16m	Up to 16m	Up to 16m	Up to 16m	Up to 16m
<b>PTO speed</b>	1000 RPM	1000 RPM	1000 RPM	1000 RPM	1000 RPM	1000 RPM
<b>Floor plate</b>	5mm	5mm	5mm	5mm	5mm	5mm
<b>Side plate</b>	4mm	4mm	4mm	4mm	4mm	4mm

## 17. MACHINE DIMENSIONS



MODEL	A	B	C	D	E	F	G
75	4200	1500	990	1970	6500	2630	2640
90	5200	1500	990	2010	7560	2670	2680
105	5200	1500	1230	2350	7560	2920	3060
105C	4200	1500	1270	2383	6515	2920	3060
120	5500	1500	1290	2410	7950	2920	3060
150	6000	1500	1290	2420	8350	2920	3080

Bunning tolerance +/- 2%

**This manual should stay with the machine/operator at all times.**

This manual is an original English language copy